



# HOSHIZAKI

## Parts List

Self-Contained Cuber

Models

AM-50BAJ

AM-50BAJ-DS

AM-50BAJ-AD

AM-50BAJ-ADDS



[hoshizakiamerica.com](http://hoshizakiamerica.com)

Number: 71397  
Issued: 12-27-2017  
Revision: 1-31-2023

## CONTENTS

|                                  |    |
|----------------------------------|----|
| Auxiliary Codes.....             | 3  |
| Note About Ordering Parts .....  | 4  |
| A. Main Assembly .....           | 5  |
| B. Refrigeration Circuit.....    | 7  |
| C. Water Circuit.....            | 9  |
| D. Control Box Assembly.....     | 11 |
| E. Door Assembly .....           | 12 |
| AM-50BAJ, AM-50BAJ-AD .....      | 12 |
| AM-50BAJ-DS, AM-50BAJ-ADDS ..... | 13 |
| F. Accessories & Labels .....    | 14 |

## Auxiliary Codes

### AM-50BAJ

G-0 October 2017  
H-0 January 2018  
H-1 September 2018  
J-0 January 2019  
J-1 October 2019  
K-0 January 2020  
K-1 May 2020  
L-0 January 2021  
M-0 February 2022  
M-1 July 2022  
M-2 December 2022  
N-0 January 2023

### AM-50BAJ-DS

G-0 October 2017  
H-0 January 2018  
H-1 September 2018  
J-0 January 2019  
J-1 October 2019  
K-0 January 2020  
K-1 July 2020  
L-0 January 2021  
M-0 January 2022  
M-1 July 2022  
N-0 January 2023

### AM-50BAJ-AD

G-0 October 2017  
H-0 January 2018  
H-1 September 2018  
J-0 January 2019  
J-1 October 2019  
K-0 January 2020  
K-1 May 2020  
L-0 January 2021  
M-0 February 2022  
M-1 July 2022  
M-2 December 2022  
N-0 January 2023

### AM-50BAJ-ADDS

G-0 October 2017  
H-0 January 2018  
H-1 September 2018  
J-0 January 2019  
K-0 January 2020  
K-1 July 2020  
L-0 February 2021  
M-0 February 2022  
M-1 August 2022  
N-0 January 2023

| <b>Beginning Serial Numbers for Front Panel Change</b> |                    |                            |
|--------------------------------------------------------|--------------------|----------------------------|
| <b>Model</b>                                           | <b>Part Number</b> | <b>Serial Number Break</b> |
| <b>AM-50BAJ</b>                                        | <b>3X6433-01</b>   | <b>H12215J and Earlier</b> |
|                                                        | <b>2A8926-01</b>   | <b>H12216J and Later</b>   |
| <b>AM-50BAJ-AD</b>                                     | <b>3X6433-02</b>   | <b>H11660J and Earlier</b> |
|                                                        | <b>2A8926-02</b>   | <b>H11661J and Later</b>   |

## Auxiliary Code Breakdown

The auxiliary code is the first two characters in the serial number. The first character indicates the year. Years progress or regress in alphabetical order. The series runs from "A" through "V" and the letters "I" and "O" are skipped. The second character indicates significant part changes within a year. Base is "0" and this number advances for each change. In cases where there is a letter in parentheses, this designates the month. This is the last character in the serial number. The series runs from "(A)" through "(M)" and the letter "(I)" is skipped. This designation is only included when identifying a parts change within an auxiliary code.

## Note About Ordering Parts

Most assemblies cannot be ordered as complete units; parts in the assemblies generally must be ordered separately.

G-0 to N-0




| Title: A. Main Assembly Model: AM-50BAJ, AM-50BAJ-DS, AM-50BAJ-AD, AM-50BAJ-ADDS |                                                 |                              |             |                 |                     |                |            |  |  |  |  |
|----------------------------------------------------------------------------------|-------------------------------------------------|------------------------------|-------------|-----------------|---------------------|----------------|------------|--|--|--|--|
| Index No.                                                                        | Description                                     | Material or Model Number     | Part Number | Required Number |                     |                |            |  |  |  |  |
|                                                                                  |                                                 |                              |             | G-0 to H-0      | *H-1 (J) to J-0 (C) | J-0 (D) to K-1 | L-0 to N-0 |  |  |  |  |
| 1                                                                                | Front Panel<br>*See page 4 for Aux. Code Break. | AM-50BAJ                     | 3X6433-01   | 1               | -                   |                |            |  |  |  |  |
|                                                                                  |                                                 |                              | *2A8926-01  |                 | *1                  | 1              | 1          |  |  |  |  |
|                                                                                  |                                                 | AM-50BAJ-DS                  | 3X6433-01   | 1               | -                   |                |            |  |  |  |  |
|                                                                                  |                                                 |                              | 2A8926-01   |                 | 1                   | 1              | 1          |  |  |  |  |
|                                                                                  |                                                 | AM-50BAJ-AD                  | 3X6433-02   | 1               | -                   |                |            |  |  |  |  |
|                                                                                  |                                                 |                              | *2A8926-02  |                 | *1                  | 1              | 1          |  |  |  |  |
|                                                                                  |                                                 | AM-50BAJ-ADDS                | 3X6433-02   | 1               | -                   |                |            |  |  |  |  |
|                                                                                  |                                                 |                              | 2A8926-02   |                 | 1                   | 1              | 1          |  |  |  |  |
| 1a                                                                               | Screw                                           |                              | 7P32-0410   |                 | *2                  | 2              | 2          |  |  |  |  |
| 2                                                                                | Louver                                          |                              | 2H5560-01   | 1               | 1                   | 1              | 1          |  |  |  |  |
| 3                                                                                | Top Panel                                       |                              | 2A2849G01   | 1               | 1                   | 1              | 1          |  |  |  |  |
| 4                                                                                | Bin Control Thermostat Bulb Holder              |                              | 3X6381-01   | 1               | 1                   | 1              | -          |  |  |  |  |
|                                                                                  |                                                 |                              | 2A9795-01   |                 |                     |                | 1          |  |  |  |  |
| 4a                                                                               | Thumbscrew                                      |                              | 415949G10   | 2               | 2                   | 2              | 2          |  |  |  |  |
| 5                                                                                | Bin Control Thermostat Assembly                 |                              | 3A2561A02   | 1               | 1                   | 1              | 1          |  |  |  |  |
| 6                                                                                | Slope                                           |                              | 3X6383-01   | 1               | 1                   | 1              | 1          |  |  |  |  |
| 7                                                                                | Scoop Holder                                    |                              | 4Y0213-01   | 1               | 1                   | 1              | 1          |  |  |  |  |
| 7a                                                                               | Thumbscrew                                      |                              | 415949G10   | 2               | 2                   | 2              | 2          |  |  |  |  |
| 8                                                                                | Leg                                             |                              | 4A2966-01   | 4               | 4                   | 4              | 4          |  |  |  |  |
| 9                                                                                | Power Supply Cord                               |                              | 4A2860-01   | 1               | 1                   | -              |            |  |  |  |  |
|                                                                                  |                                                 |                              | 4A5718-01   |                 |                     | 1              | 1          |  |  |  |  |
| 10                                                                               | Hinge A                                         | AM-50BAJ<br>AM-50BAJ-AD      | 4Y0194G01   | 1               | 1                   | 1              | 1          |  |  |  |  |
|                                                                                  | Right Hinge A                                   | AM-50BAJ-DS<br>AM-50BAJ-ADDS | 4A4885G01   | 1               | 1                   | 1              | 1          |  |  |  |  |
| 11                                                                               | Hinge A Bracket                                 |                              | 4A2996-01   | 1               | 1                   | 1              | 1          |  |  |  |  |
| 11a                                                                              | Screw                                           |                              | 7C32-0410   | 1               | 1                   | 1              | 1          |  |  |  |  |
| 12                                                                               | Top Brace                                       |                              | 4Y0193-01   | 1               | 1                   | 1              | 1          |  |  |  |  |
| 12a                                                                              | Screw                                           |                              | 7C32-0410   | 1               | 1                   | 1              | 1          |  |  |  |  |
| 13                                                                               | Hinge B                                         | AM-50BAJ<br>AM-50BAJ-AD      | 4Y0192-01   | 1               | 1                   | 1              | 1          |  |  |  |  |
|                                                                                  |                                                 | AM-50BAJ-DS<br>AM-50BAJ-ADDS | 4A3980-01   | 1               | 1                   | 1              | 1          |  |  |  |  |
| 13a                                                                              | Flat Head Screw                                 | 4x12, SS                     | 7C22-0412   | 2               | 2                   | 2              | 2          |  |  |  |  |
| 14                                                                               | Hinge Stop Pin                                  |                              | 4A2180-01   | 1               | 1                   | 1              | 1          |  |  |  |  |
| 15                                                                               | Tooth Washer                                    |                              | 7R22-0600   | 1               | 1                   | 1              | 1          |  |  |  |  |
| 16                                                                               | Rear Panel                                      | AM-50BAJ<br>AM-50BAJ-DS      | 2A3304-01   | 1               | 1                   | 1              | 1          |  |  |  |  |
|                                                                                  |                                                 | AM-50BAJ-AD<br>AM-50BAJ-ADDS | 2A3305-01   | 1               | 1                   | 1              | 1          |  |  |  |  |
| 17                                                                               | Pipe Cover                                      |                              | 3X6432-01   | 1               | 1                   | 1              | 1          |  |  |  |  |
| 18                                                                               | Control Box Cover                               |                              | 3A7744-01   | 1               | 1                   | 1              | 1          |  |  |  |  |

## B. Refrigeration Circuit

AM-50BAJ, AM-50BAJ-DS, AM-50BAJ-AD, AM-50BAJ-ADDS

G-0 to N-0




| Title: B. Refrigeration Circuit    Model: AM-50BAJ, AM-50BAJ-DS, AM-50BAJ-AD, AM-50BAJ-ADDS |                                      |                          |             |                 |            |            |  |  |  |  |  |
|---------------------------------------------------------------------------------------------|--------------------------------------|--------------------------|-------------|-----------------|------------|------------|--|--|--|--|--|
| Index No.                                                                                   | Description                          | Material or Model Number | Part Number | Required Number |            |            |  |  |  |  |  |
|                                                                                             |                                      |                          |             | G-0 to K-1      | L-0 to M-0 | M-1 to N-0 |  |  |  |  |  |
| 1                                                                                           | Compressor                           |                          | 455942-01   | 1               | 1          | 1          |  |  |  |  |  |
| 2                                                                                           | PTC Relay                            |                          | 456252-01   | 1               | 1          | 1          |  |  |  |  |  |
| 3                                                                                           | Motor Protector                      |                          | 456254-01   | 1               | 1          | 1          |  |  |  |  |  |
| 4                                                                                           | Condenser                            |                          | 2H5586-01   | 1               | 1          | 1          |  |  |  |  |  |
| 5                                                                                           | Fan Motor                            |                          | 440916-01   | 1               | 1          | -          |  |  |  |  |  |
|                                                                                             |                                      |                          | 4A7228-01   |                 |            | 1          |  |  |  |  |  |
| 6                                                                                           | Fan Blade                            |                          | 3A4467-01   | 1               | 1          | 1          |  |  |  |  |  |
| 6a                                                                                          | Washer                               |                          | 435983-01   | 1               | 1          | 1          |  |  |  |  |  |
| 6b                                                                                          | Hex Nut                              |                          | 4A1345-01   | 1               | 1          | 1          |  |  |  |  |  |
| 7                                                                                           | Valve Body                           |                          | 4A3275-01   | 1               | 1          | 1          |  |  |  |  |  |
| 8                                                                                           | Valve Coil                           |                          | 4A3277-01   | 1               | 1          | 1          |  |  |  |  |  |
| 9                                                                                           | Evaporator                           |                          | 3X3948G01   | 1               | -          |            |  |  |  |  |  |
|                                                                                             |                                      |                          | 2X3515G01   |                 | 1          | 1          |  |  |  |  |  |
| 10                                                                                          | Thermistor                           |                          | 425373-05   | 1               | 1          | 1          |  |  |  |  |  |
| 11                                                                                          | Thermistor Holder                    |                          | 3H9642-01   | 1               | 1          | 1          |  |  |  |  |  |
| 12                                                                                          | Strainer                             |                          | 441569-01   | 1               | 1          | 1          |  |  |  |  |  |
| 13                                                                                          | Drier                                |                          | 445655-04   | 1               | 1          | 1          |  |  |  |  |  |
| 14                                                                                          | Heat Exchanger<br>(includes item 15) |                          | 3X6438G01   | 1               | 1          | -          |  |  |  |  |  |
|                                                                                             |                                      |                          | 3B1346G01   |                 |            | 1          |  |  |  |  |  |
| 15                                                                                          | Accumulator                          |                          | 460537-02   | 1               | 1          | 1          |  |  |  |  |  |

## C. Water Circuit

**AM-50BAJ, AM-50BAJ-DS, AM-50BAJ-AD, AM-50BAJ-ADDS**

G-0 to N-0




| Title: C. Water Circuit Model: AM-50BAJ, AM-50BAJ-DS, AM-50BAJ-AD, AM-50BAJ-ADDS |                   |                          |             |                 |            |     |  |  |  |  |  |  |
|----------------------------------------------------------------------------------|-------------------|--------------------------|-------------|-----------------|------------|-----|--|--|--|--|--|--|
| Index No.                                                                        | Description       | Material or Model Number | Part Number | Required Number |            |     |  |  |  |  |  |  |
|                                                                                  |                   |                          |             | G-0 to K-0      | K-1 to M-2 | N-0 |  |  |  |  |  |  |
| 1                                                                                | Pump Motor        | SP-5219                  | 3A8334-01   | 1               | 1          | -   |  |  |  |  |  |  |
|                                                                                  |                   |                          | 3B1175-01   |                 |            | 1   |  |  |  |  |  |  |
| 2                                                                                | Inlet Water Valve |                          | 458548-01   | 1               | -          |     |  |  |  |  |  |  |
|                                                                                  |                   |                          | 4A6722-01   |                 | 1          | 1   |  |  |  |  |  |  |
| 3                                                                                | Rubber Gasket     |                          | 413854-03   | 1               | 1          | 1   |  |  |  |  |  |  |
| 4                                                                                | Fitting C         |                          | 4A3240-01   | 1               | 1          | 1   |  |  |  |  |  |  |
| 5                                                                                | Water Valve Tube  |                          | 4X7938-01   | 1               | 1          | 1   |  |  |  |  |  |  |
| 6                                                                                | Separator         |                          | 3A9811-01   | 6               | 6          | 6   |  |  |  |  |  |  |
| 7                                                                                | Ice Chute         |                          | 3X3863-01   | 1               | 1          | 1   |  |  |  |  |  |  |
| 8                                                                                | Nozzle            |                          | 2H4536-01   | 1               | 1          | 1   |  |  |  |  |  |  |
| 9                                                                                | Cap               |                          | 4X7936-01   | 2               | 2          | 2   |  |  |  |  |  |  |
| 10                                                                               | Reducing Pipe     |                          | 4A2903-01   | 1               | 1          | 1   |  |  |  |  |  |  |
| 11                                                                               | Water Tank        |                          | 2H4535-01   | 1               | 1          | 1   |  |  |  |  |  |  |
| 12                                                                               | Suction Tube      |                          | 4X7937-01   | 1               | 1          | 1   |  |  |  |  |  |  |
| 13                                                                               | Joint             |                          | 4X7934-01   | 1               | 1          | 1   |  |  |  |  |  |  |
| 14                                                                               | Discharge Tube    |                          | 3X3864-01   | 1               | 1          | 1   |  |  |  |  |  |  |
| 15                                                                               | Drain Pan         |                          | 2H4534-01   | 1               | 1          | 1   |  |  |  |  |  |  |
| 16                                                                               | Drain Tube        |                          | 4H2585-01   | 1               | 1          | 1   |  |  |  |  |  |  |
| 17                                                                               | Drain Pipe        |                          | 4Y0211-01   | 1               | 1          | 1   |  |  |  |  |  |  |
| 18                                                                               | Elbow Hose        |                          | 4A1165-08   | 1               | 1          | 1   |  |  |  |  |  |  |
| 19                                                                               | Drain Fitting     |                          | 4A3488G01   | 1               | 1          | 1   |  |  |  |  |  |  |
| Hose Clamps                                                                      |                   |                          |             |                 |            |     |  |  |  |  |  |  |
| 20                                                                               | Hose Clamp        | 22-25 mm                 | 4A2017-09   | 2               | 2          | 2   |  |  |  |  |  |  |
| 21                                                                               | Hose Clamp        | 13-15 mm                 | 4A2017-08   | 1               | 1          | 1   |  |  |  |  |  |  |


## D. Control Box Assembly

### AM-50BAJ, AM-50BAJ-DS, AM-50BAJ-AD, AM-50BAJ-ADDS


G-0 to N-0



Auxiliary Code: J-0 and Earlier




Auxiliary Code: J-1 to M-2



Auxiliary Code: N-0 and Later


| Title: D. Control Box Assembly Model: AM-50BAJ, AM-50BAJ-DS, AM-50BAJ-AD, AM-50BAJ-ADDS |                       |                          |             | Required Number |            |            |     |  |  |  |  |
|-----------------------------------------------------------------------------------------|-----------------------|--------------------------|-------------|-----------------|------------|------------|-----|--|--|--|--|
| Index No.                                                                               | Description           | Material or Model Number | Part Number | G-0 to J-0      | J-1 to L-0 | M-0 to M-2 | N-0 |  |  |  |  |
| 1                                                                                       | Control Board         |                          | 4A5520-01   | 1               | 1          | 1          | 1   |  |  |  |  |
| 1a                                                                                      | Control Board Support |                          | 4A0336-03   | 4               | 4          | 4          | 4   |  |  |  |  |
| 2                                                                                       | Control Switch        |                          | 443119-01   | 1               | 1          | 1          | 1   |  |  |  |  |
| 3                                                                                       | Cap                   |                          | 4A1937-01   | 1               | 1          | 1          | 1   |  |  |  |  |
| 4                                                                                       | Control Transformer   |                          | 4A0557-01   | 1               | 1          | 1          | 1   |  |  |  |  |
| 5                                                                                       | Fuse Holder           |                          | 4A5443-01   |                 | 1          | 1          | 1   |  |  |  |  |
| 6                                                                                       | Fuse                  | 1.0 A                    | 4A0893-01   |                 | 1          | -          |     |  |  |  |  |
|                                                                                         |                       | 1.25 A                   | 4A0893-11   |                 |            | 1          | -   |  |  |  |  |
|                                                                                         |                       | 0.375 A                  | 4A0893-12   |                 |            |            | 1   |  |  |  |  |
| 7                                                                                       | Pump Capacitor        | 1 MFD                    | 4A2128-10   |                 |            |            | 1   |  |  |  |  |

**E. Door Assembly**  
**AM-50BAJ, AM-50BAJ-AD**  
 G-0 to N-0



| Title: E. Door Assembly    Model: AM-50BAJ, AM-50BAJ-AD |                                               |                          |             |            |                 |  |  |  |  |  |
|---------------------------------------------------------|-----------------------------------------------|--------------------------|-------------|------------|-----------------|--|--|--|--|--|
| Index No.                                               | Description                                   | Material or Model Number | Part Number | G-0 to N-0 | Required Number |  |  |  |  |  |
|                                                         |                                               |                          |             |            |                 |  |  |  |  |  |
| 1                                                       | Door Assembly<br>(includes items 2 through 6) | AM-50BAJ                 | SP-5339     | 1          |                 |  |  |  |  |  |
|                                                         |                                               | AM-50BAJ-AD              | SP-5340     | 1          |                 |  |  |  |  |  |
| 2                                                       | Bushing                                       |                          | 4A6410-01   | 1          |                 |  |  |  |  |  |
| 3                                                       | Gasket                                        |                          | 2A3017-01   | 1          |                 |  |  |  |  |  |
| 4                                                       | Handle                                        | AM-50BAJ                 | 4A6129-01   | 1          |                 |  |  |  |  |  |
|                                                         |                                               | AM-50BAJ-AD              | 4A6129-02   | 1          |                 |  |  |  |  |  |
| 5                                                       | Magnet Holder                                 |                          | 4Y0203-01   | 1          |                 |  |  |  |  |  |
| 5a                                                      | Truss Head Screw                              |                          | 7C32-0408   | 2          |                 |  |  |  |  |  |
| 6                                                       | Magnet                                        |                          | 4A4686-01   | 3          |                 |  |  |  |  |  |

**E. Door Assembly**  
**AM-50BAJ-DS, AM-50BAJ-ADDS**  
 G-0 to N-0




| Title: F. Door Assembly    Model: AM-50BAJ-DS, AM-50BAJ-ADDS |                                                       |                          |             |            |                 |  |  |  |  |  |  |  |
|--------------------------------------------------------------|-------------------------------------------------------|--------------------------|-------------|------------|-----------------|--|--|--|--|--|--|--|
| Index No.                                                    | Description                                           | Material or Model Number | Part Number | G-0 to N-0 | Required Number |  |  |  |  |  |  |  |
|                                                              |                                                       |                          |             |            |                 |  |  |  |  |  |  |  |
| 1                                                            | Door Assembly<br>(includes items 2 through 4)         | AM-50BAJ-DS              | SP-5334     | 1          |                 |  |  |  |  |  |  |  |
|                                                              |                                                       | AM-50BAJ-ADDS            | SP-5333     | 1          |                 |  |  |  |  |  |  |  |
| 2                                                            | Bushing                                               |                          | 4A6410-01   | 2          |                 |  |  |  |  |  |  |  |
| 3                                                            | Gasket                                                |                          | 2A3017-01   | 1          |                 |  |  |  |  |  |  |  |
| 4                                                            | Hinge C Assembly (UR, LL)<br>(includes one of item 2) |                          | 4A3983G01   | 1          |                 |  |  |  |  |  |  |  |
| 4a                                                           | Flat Head Screw                                       | 4x12, SS                 | 7C22-0412   | 2          |                 |  |  |  |  |  |  |  |
| 5                                                            | Hinge C Assembly (LR, UL)<br>(includes one of item 2) |                          | 4A3983G02   | 1          |                 |  |  |  |  |  |  |  |
| 5a                                                           | Flat Head Screw                                       | 4x12, SS                 | 7C22-0412   | 2          |                 |  |  |  |  |  |  |  |
| 6                                                            | Magnet Holder                                         |                          | 4Y0203-01   | 1          |                 |  |  |  |  |  |  |  |
| 6a                                                           | Truss Head Screw                                      |                          | 7C32-0408   | 2          |                 |  |  |  |  |  |  |  |
| 7                                                            | Magnet                                                |                          | 4A4686-01   | 3          |                 |  |  |  |  |  |  |  |

## F. Accessories & Labels

### AM-50BAJ, AM-50BAJ-DS, AM-50BAJ-AD, AM-50BAJ-ADDS

G-0 to N-0



| Title: F. Accessories & Labels    Model: AM-50BAJ, AM-50BAJ-DS, AM-50BAJ-AD, AM-50BAJ-ADDS |                      |                              |             |                 |  |  |  |  |  |  |  |  |
|--------------------------------------------------------------------------------------------|----------------------|------------------------------|-------------|-----------------|--|--|--|--|--|--|--|--|
| Index No.                                                                                  | Description          | Material or Model Number     | Part Number | Required Number |  |  |  |  |  |  |  |  |
|                                                                                            |                      |                              |             | G-0 to N-0      |  |  |  |  |  |  |  |  |
| 1                                                                                          | Hoshizaki Emblem     | AM-50BAJ<br>AM-50BAJ-AD      | 4A0560-01   | 1               |  |  |  |  |  |  |  |  |
| 2                                                                                          | Scoop                |                              | 204336-01   | 1               |  |  |  |  |  |  |  |  |
| 3                                                                                          | Control Label        |                              | 463253-01   | 1               |  |  |  |  |  |  |  |  |
| 4                                                                                          | Canoe Clip           |                              | 4A5835-01   | 2               |  |  |  |  |  |  |  |  |
| 5                                                                                          | Sheet Metal Bracket  | AM-50BAJ-DS<br>AM-50BAJ-ADDS | 4A3998-01   | 1               |  |  |  |  |  |  |  |  |
| 6                                                                                          | Threaded Wood Insert | AM-50BAJ-DS<br>AM-50BAJ-ADDS | 4A4004-01   | 6               |  |  |  |  |  |  |  |  |
| 7                                                                                          | Pan Head Screw       | AM-50BAJ-DS<br>AM-50BAJ-ADDS | 7C12-0425   | 4               |  |  |  |  |  |  |  |  |
| 8                                                                                          | Truss Head Screw     | AM-50BAJ-DS<br>AM-50BAJ-ADDS | 7C32-0408   | 2               |  |  |  |  |  |  |  |  |
| 9                                                                                          | T2 Screw             | AM-50BAJ-DS<br>AM-50BAJ-ADDS | 7P32-0408   | 3               |  |  |  |  |  |  |  |  |