

HOW TO READ A MODEL NUMBER





TABLE OF CONTENTS

Manitowoc Foodservice [Updated: Apr. 23, 2015]	
Manitowoc - Ice & Related	
Parts Catalog	
Ice Machine	
Indigo Series	
Indigo Model - QuietQube	
i2176C, iCVD2096 Indigo	
i2176C Head Section - Control Box Components	
i2176C Evaporator Compartment - Common Components	3
i2176C Refrigeration Compartment - Common Components	6
i2176C Head Section - Panels	
iCVD2096 Condensing Unit	1 1
iCVD2096 Condensing Unit - Control Box	13
iCVD2096 Condensing Unit Panels	15



12176C HEAD SECTION - CONTROL BOX COMPONENTS





12176C HEAD SECTION - CONTROL BOX COMPONENTS


#	PART#	DESCRIPTION	QTY	Note
1	000008309	Control Board		
1a	000009181	8 amp Ceramic Fuse - Mounted on Control Board		
2	8373263	Refrigeration Service Valve Assembly		
2a	000008049	Refrigeration Service Valve Bracket		
2b	2502189	Bushing - 0.625"		
2c	5202099	Screw - #10-24 x 0.50" PHIL		
3	000006728	LCD Display		
4	000008031	Touch Pad with Housing		
5	000007737	LCD Wiring Harness - 30" Long		
6	000007902	Touch Pad/Housing Mounting Bracket		
7		Front Panel LCD Frame		
7a	000006647	LCD Frame with Key Guard		
7b	000006564	LCD Frame without Key Guard		
7c	K00433	Display Cover		[1]
8	000007962	Control Box		
9	000009953	Control Box Cover		
10	4302253	Control Board Mounting Supports		
11	5202169	Screw - #10-24 x 0.50" Ground		
11a	5573209	Star Washer		
12	2500169	Bushing - 0.91" OD x 0.44" ID		
13		Control Box Wiring Harness		
13a	000008464	Control Box Wiring Harness - 115V/60 Hz/1 Ph		
13b	000001931	Control Box Wiring Harness - 230V/50 Hz/1 Ph		
14		Refrigeration Compartment Wiring Harness		
14a	000010514	Refrigeration Compartment Wiring Harness - 230V/50 Hz/1 Ph		

PART NOTES:

[1] - hides the display completely



I2176C EVAPORATOR COMPARTMENT - COMMON COMPONENTS





I2176C EVAPORATOR COMPARTMENT - COMMON COMPONENTS

#	PART#	DESCRIPTION	QTY	Note
1		Evaporator Assembly		
1a	000011476	Evaporator - Dice Cube		
1b	000011475	Evaporator - Half Dice Cube		
2		Water Pump		
2a	000001153	Water Pump - 115V/60 Hz		
2b	000000259	Water Pump - 230V/50 Hz		
3	000007052	Water Level Probe		
3a	000007053	Water Level Probe - Holder		
3b	000008027	Mounting Bracket Plastic		
3c	000007099	Wire - Control Box to Probe		
3d	5202099	Screw - #10-24 x 0.50" PHIL		[1]
4	000008660	Ice Thickness Control Probe		
5	000001756	Magnetic Bin Switch		
5a	000007441	Bin Switch Wiring Harness		
5b	000001421	Bin Switch Covers		
6	7602193	Water Distribution Tube - 30" L		
6a	000001118	Molded Vinyl Tube		[2]
6b	000001117	Molded Vinyl Tube		[3]
6c	000001986	Barbed Fitting		
6d	5650609	Snap Clamp - 1.0" ID		[4]
6e	5650539	Snap Clamp - 1.123 x 1.296		[5]
6f	4014693	Fitting		[6]
6g	000002465	Fitting Bracket		
7	000002056	Ice Damper Assembly		
8	000009176	Splash Shields		
9	000009118	Front Splash Shield		
10	000001097	Water Trough		
11	000002190	Front Panel Mount		
12	000002176	Evaporator Top Filler Covers		
13	000002307	Evaporator Right/Left Filler Panels		
14	000002786	Evaporator Top Frame Assembly		
15	000001416	Evaporator Bottom Covers		
16	000001143	Evaporator Bottom Frame		
17	5004799	Thumbscrew SS - #8-32 x 0.375"		
17a	5004629	O-Ring - 0.125" ID		
18	5012319	Screw - #12-16 x 0.75"		
19	000008028	Water Pump Mount		
20	5004659	Water Pump Base O-Ring - 4.00" ID		
21	5004679	Water Pump Outlet O-Ring - 0.875" ID		
22	5202069	Screw - #10-24 x 0.50" HEX		[7]
23	000002476	Washer		[7]

PART NOTES:

[1] - to mount water level probe holder[2] - to Right Hand Distribution Tube



I2176C EVAPORATOR COMPARTMENT - COMMON COMPONENTS

PART NOTES:

[3] - to Left Hand Distribution Tube

[4] - for barbed fitting


[5] - vinyl tubes to distribution tubes

[6] - through bulkhead

[7] - water pump to pump mount



12176C REFRIGERATION COMPARTMENT - COMMON COMPONENTS





12176C REFRIGERATION COMPARTMENT - COMMON COMPONENTS

Water Dump Valve 115V/60 Hz	#	PART#	DESCRIPTION	QTY	Note
10			Water Dump Valve		
1c	1a	000001767	Water Dump Valve - 115V/60 Hz		
2	1b	000001768	Water Dump Valve - 208-230V/50-60 Hz		
2 Marvest Valve 2a 00007018 Solenoid Valve Including 115V/80 Hz Electrical Coil 2b 000007018 Solenoid Valve Coil Only - 115V/60 Hz [1] 2c 000007018 Solenoid Valve Coil Only - 115V/60 Hz [2] 2d 00000719 Danfoss Solenoid Valve Coil Only - 230V/50-60 Hz [2] 3a Water Inlet Valve with Bracket Valve Inlet Valve - 115V/60 Hz/1 Ph [3] 3b 000009122 Water Inlet Valve - 208-230V/50-60 Hz [4] 4 000011513 Expansion Valve [8] 4a 4000403 Valve Insulation Boot - Body [8] 4b 4000923 Valve Insulation Boot - Body [8] 4a 4000403 Valve Insulation Boot - Body [8] 5a 8373283	1c	000001911	Dump Valve Mounting Bracket		
2b	2				
2b	2a	000007018	Solenoid Valve Including 115V/60 Hz Electrical Coil		
2c 000007015 Solenoid Valve Including - 208-230V/50-60 Hz Electrical Coil 2d 000005157 Danfoss Solenoid Valve Coil Only - 230V/50-60 Hz [2] 3	2b		_		[1]
2d			•		
3	2d				[2]
3a 000009123 Water Inlet Valve - 115V/60 Hz/1 Ph 3b 000009122 Water Inlet Valve - 208-230V/50-60 Hz 4 00001513 Expansion Valve 4a 4000403 Valve Insulation Boot - Body 4b 4000923 Valve Insulation Boot - Bulb 5 8373283 Manual Shut-off Valve - 0.75" 5a 6036261 Bracket - 3/4" Valve 6 8373303 Manual Shut-off Valve - 0.625" 6a 8036721 Bracket - 1/2" Valve 7a 00000718 Solenoid Valve Including 115V/60 Hz Electrical Coil 7b 000005156 Danfoss Solenoid Valve Coil Only - 115V/60 Hz [1] 7c 00000717 Solenoid Valve Including 208-230V/50-60 Hz Electrical Coil [2] 8a 7629603 Receiver 8b 7629603 Receiver 8c 8307214 Receiver Mounting Strap 9 000001780 Top Bracket - Receiver 8c 8307214 Receiver Mounting Strap 9 000001280 Check Valve 10 <td>3</td> <td></td> <td></td> <td></td> <td></td>	3				
3b	3a	000009123	Water Inlet Valve - 115V/60 Hz/1 Ph		
4 000011513 Expansion Valve 4a 4000403 Valve Insulation Boot - Body 4b 4000923 Valve Insulation Boot - Bulb 5 8373283 Manual Shut-off Valve - 0.75" 5a 6036261 Bracket - 3/4" Valve 6 8373303 Manual Shut-off Valve - 0.625" 6a 8036721 Bracket - 1/2" Valve 7 Liquid Line Solenoid Valve 8a 00007018 Solenoid Valve Including 115V/60 Hz Electrical Coil 7b 00005156 Danfoss Solenoid Valve Coil Only - 115V/60 Hz [1] 7c 000007017 Solenoid Valve Including 208-230V/50-60 Hz Electrical Coil [2] 8a 7629603 Receiver [2] 8a 7629603 Receiver [2] 8b 000001730 Top Bracket - Receiver 8c 6307214 Receiver Mounting Strap 9 00001290 Check Valve 10 00000283 Drier 11b 000007222 Air Assist - 115V/60 Hz 11c 4011733 </td <td>3b</td> <td></td> <td>Water Inlet Valve - 208-230V/50-60 Hz</td> <td></td> <td></td>	3b		Water Inlet Valve - 208-230V/50-60 Hz		
4a 4000403 Valve Insulation Boot - Body 4b 4000923 Valve Insulation Boot - Bulb 5 8373283 Manual Shut-off Valve - 0.75" 5a 6036261 Bracket - 3/4" Valve 6 8373303 Manual Shut-off Valve - 0.625" 6a 6036721 Bracket - 1/2" Valve 7a 000007018 Solenoid Valve Including 115V/60 Hz Electrical Coil 7b 000005156 Danfoss Solenoid Valve Coil Only - 115V/60 Hz [1] 7c 000007017 Solenoid Valve Including 208-230V/50-60 Hz Electrical Coil [2] 7d 000005157 Danfoss Solenoid Valve Coil Only - 230V/50-60 Hz [2] 8a 000001779 Bottom Bracket - Receiver 8a 000001779 Bottom Bracket - Receiver 8c 6307214 Receiver Mounting Strap 9 000001290 Check Valve 10 00000283 Drier 11a 000007222 Air Assist - 230V/50-60 Hz 11b 000007223 Air Assist Bracket 12c K00434 Luminloe	4		Expansion Valve		
4b 4000923 Valve Insulation Boot - Bulb 5 8373283 Manual Shut-off Valve - 0.75" 5a 6036261 Bracket - 3/4" Valve 6 8373303 Manual Shut-off Valve - 0.625" 6a 8036721 Bracket - 1/2" Valve 7 Liquid Line Solenoid Valve 7a 000007018 Solenoid Valve Including 115V/60 Hz [1] 7c 000007017 Solenoid Valve Coil Only - 115V/60 Hz [1] 7c 000007017 Solenoid Valve Coil Only - 230V/50-60 Hz Electrical Coil 7d 000005157 Danfoss Solenoid Valve Coil Only - 230V/50-60 Hz [2] 8 7629603 Receiver 8a 0000179 Bottom Bracket - Receiver 8b 00001780 Top Bracket - Receiver 8c 6307214 Receiver Mounting Strap 9 000001290 Check Valve 10 00000283 Drier 11a 000007223 Air Assist - 115V/60 Hz 11b 000007223 Air Assist Bracket 12c K00434	4a		·		
5 8373283 Manual Shut-off Valve - 0.75" 5a 6036261 Bracket - 3/4" Valve 6 8373303 Manual Shut-off Valve - 0.625" 6a 6036721 Bracket - 1/2" Valve 7 Liquid Line Solenoid Valve 7a 000007018 Solenoid Valve Including 115V/60 Hz Electrical Coil 7b 000007017 Solenoid Valve Including 208-230V/50-60 Hz Electrical Coil 7c 000007017 Solenoid Valve Coil Only - 115V/60 Hz [1] 7c 000007017 Solenoid Valve Coil Only - 230V/50-60 Hz [2] 8a 7629603 Receiver 8a 7629603 Receiver 8b 0000017780 Top Bracket - Receiver 8c 6307214 Receiver Mounting Strap 9 000001290 Check Valve 10 00000283 Drier 11a 000007222 Air Assist - 115V/60 Hz 11b 000007223 Air Assist Packet 12 K00434 Luminloe 12a K00425 Luminloe Bulb <	4b		•		
5a \$036261 Bracket - 3/4" Valve 6 8373303 Manual Shut-off Valve - 0.625" 6a 6036721 Bracket - 1/2" Valve 7 Liquid Line Solenoid Valve 7a 000007018 Solenoid Valve Including 115V/60 Hz Electrical Coil 7b 00000717 Solenoid Valve Locil Only - 115V/60 Hz [1] 7c 00000717 Solenoid Valve Coil Only - 230V/50-60 Hz [2] 8 7629603 Receiver 8a 000001779 Bottom Bracket - Receiver 8b 000001780 Top Bracket - Receiver 8c 6307214 Receiver Mounting Strap 9 00001290 Check Valve 10 000002883 Drier 11 Air Pumps Air Assist - 115V/60 Hz 11b 000007223 Air Assist Packet 12 K00434 Luminloe 12 K00435 Luminloe Bulb 12b 000008263 Luminloe Wiring Harness 12c 000007990 Bulkhead Fitting 2.25" 12d <td>5</td> <td></td> <td>Manual Shut-off Valve - 0.75"</td> <td></td> <td></td>	5		Manual Shut-off Valve - 0.75"		
6 8373303 Manual Shut-off Valve - 0.625" 6a 8036721 Bracket - 1/2" Valve 7 Liquid Line Solenoid Valve 7a 000007018 Solenoid Valve Including 115V/60 Hz Electrical Coil 7b 000007017 Solenoid Valve Coil Only - 115V/60 Hz [1] 7c 000007017 Solenoid Valve Coil Only - 115V/60 Hz [2] 8 7629603 Receiver 8a 000001780 Top Bracket - Receiver 8b 000001780 Top Bracket - Receiver 8c 6307214 Receiver Mounting Strap 9 000001290 Check Valve 10 000002883 Drier 11b Air Pumps Air Assist - 115V/60 Hz 11c 4011739 Air Assist - 230V/50-60 Hz 11c 4011739 Air Assist Bracket 12c K00434 Luminloe 12a K00425 Luminloe Bulb 12b 000002823 Luminloe Wiring Harness 12c 000007990 Bulkhead Fitting 2.25" 12					
6a 8036721 Bracket - 1/2" Valve 7 Liquid Line Solenoid Valve 7a 000007018 Solenoid Valve Including 115V/60 Hz Electrical Coil 7b 000007017 Solenoid Valve Coil Only - 115V/60 Hz [1] 7c 000007017 Solenoid Valve Coil Only - 1230V/50-60 Hz Electrical Coil [2] 7d 000005157 Danfoss Solenoid Valve Coil Only - 230V/50-60 Hz [2] 8 7629603 Receiver 8a 000001779 Bottom Bracket - Receiver 8b 000001780 Top Bracket - Receiver 8c 6307214 Receiver Mounting Strap 9 000001290 Check Valve 10 000002883 Drier 11b 000007222 Air Assist - 115V/60 Hz 11c 4011739 Air Assist - 230V/50-60 Hz 11c 4011739 Air Assist Bracket 12a K00434 Luminloe 12b 000008489 Air Assist Hardet 12c 000007990 Bulkhead Fitting 2.25" 12d 000008283					
77 Liquid Line Solenoid Valve 78 000007018 Solenoid Valve Including 115V/60 Hz Electrical Coil 7b 000005156 Danfoss Solenoid Valve Coil Only - 115V/60 Hz [1] 7c 00000717 Solenoid Valve Including 208-230V/50-60 Hz Electrical Coil 7d 000005157 Danfoss Solenoid Valve Coil Only - 230V/50-60 Hz [2] 8 7629603 Receiver 8a 000001779 Bottom Bracket - Receiver 8b 000001780 Top Bracket - Receiver 8c 6307214 Receiver Mounting Strap 9 000001290 Check Valve 10 000002883 Drier 11a 000007222 Air Assist - 115V/60 Hz 11b 000007223 Air Assist Bracket 12 K00434 Luminlce 12a K00425 Luminlce Bulb 12b 00008283 Luminlce Wiring Harness 12c 000007990 Bulkhead Fitting 2.25" 12d 000008269 Bulkhead Fitting 2.75" 13 000008310 Thermi					
7a 000007018 Solenoid Valve Including 115V/60 Hz Electrical Coil 7b 000005156 Danfoss Solenoid Valve Coil Only - 115V/60 Hz [1] 7c 000007017 Solenoid Valve Including 208-230V/50-60 Hz Electrical Coil 7d 000005157 Danfoss Solenoid Valve Coil Only - 230V/50-60 Hz [2] 8 7629603 Receiver 8a 000001779 Bottom Bracket - Receiver 8b 000001780 Top Bracket - Receiver 8c 6307214 Receiver Mounting Strap 9 000001290 Check Valve 10 000002833 Drier 11a 000007222 Air Assist - 115V/60 Hz 11b 000007223 Air Assist - 230V/50-60 Hz 11c 4011739 Air Manifold [3] 11d 000006489 Air Assist Bracket 12a K00434 Luminlce Bulb 12b 000008283 Luminlce Wiring Harness 12c 000007990 Bulkhead Fitting 2.25" 13 0000008269 Bulkhead Fitting 2.75"		0000.2.			
7b 000005156 Danfoss Solenoid Valve Coil Only - 115V/60 Hz [1] 7c 000007017 Solenoid Valve Including 208-230V/50-60 Hz Electrical Coil 7d 000005157 Danfoss Solenoid Valve Coil Only - 230V/50-60 Hz [2] 8 7629603 Receiver 8a 000001780 Top Bracket - Receiver 8b 000001780 Top Bracket - Receiver 8c 6307214 Receiver Mounting Strap 9 000001290 Check Valve 10 000002883 Drier 11a Air Pumps Air Assist - 115V/60 Hz 11b 000007223 Air Assist - 230V/50-60 Hz 11c 4011739 Air Manifold [3] 11d 000006483 Air Assist Bracket [3] 12 K00434 Luminloe [4] 12a K00425 Luminloe Wiring Harness 12c 00007990 Bulkhead Fitting 2.25" 12d 000007990 Bulkhead Fitting 2.75" 13 000008269 Bulkhead Fitting 2.75"		000007018	·		
7c 000007017 Solenoid Valve Including 208-230V/50-60 Hz Electrical Coil 7d 000005157 Danfoss Solenoid Valve Coil Only - 230V/50-60 Hz [2] 8 7629603 Receiver 8a 000001779 Bottom Bracket - Receiver 8b 000001780 Top Bracket - Receiver 8c 6307214 Receiver Mounting Strap 9 000001290 Check Valve 10 000002883 Drier 11 Air Pumps Air Assist - 115V/60 Hz 11b 000007222 Air Assist - 230V/50-60 Hz 11c 4011739 Air Manifold [3] 11d 000006489 Air Assist Bracket 12 K00434 LuminIce 12a K00425 LuminIce Wiring Harness 12c 000008283 LuminIce Wiring Harness 12c 000008269 Bulkhead Fitting 2.25" 13 000008310 Thermistor with Spring Clips 14 8706093 Female Wing Adapter - 0.375" 15 1360961 Male Connector	-		-		[1]
7d 000005157 Danfoss Solenoid Valve Coil Only - 230V/50-60 Hz [2] 8 7629603 Receiver 8a 000001779 Bottom Bracket - Receiver 8b 000001780 Top Bracket - Receiver 8c 6307214 Receiver Mounting Strap 9 000001290 Check Valve 10 000002883 Drier 11 Air Pumps Air Assist - 115V/60 Hz 11b 000007222 Air Assist - 230V/50-60 Hz 11c 4011739 Air Manifold [3] 11d 000006489 Air Assist Bracket 12 K00434 LuminIce 12a K00425 LuminIce Bulb 12b 000008283 LuminIce Wiring Harness 12c 000007990 Bulkhead Fitting 2.75" 13 000008310 Thermistor with Spring Clips 14 8706093 Female Wing Adapter - 0.375" 15 1360961 Male Connector 16 8706083 Female Wing Adapter - 0.50" 17			•		[.]
8 7629603 Receiver 8a 000001779 Bottom Bracket - Receiver 8b 000001780 Top Bracket - Receiver 8c 6307214 Receiver Mounting Strap 9 000001290 Check Valve 10 000002883 Drier 11a Air Pumps 11a 000007222 Air Assist - 115V/60 Hz 11b 000007223 Air Assist - 230V/50-60 Hz 11c 4011739 Air Manifold [3] 11d 00006489 Air Assist Bracket 12 K00434 Luminlce 12a K00425 Luminlce Wiring Harness 12b 000008283 Luminlce Wiring Harness 12c 000007990 Bulkhead Fitting 2.25" 12d 000008269 Bulkhead Fitting 2.75" 13 00008310 Thermistor with Spring Clips 14 8706093 Female Wing Adapter - 0.375" 15 1360961 Male Connector 16 8706083 Female Wing Adapter - 0.50" 17 000002340 Water Drain Tubing					[2]
8a 000001779 Bottom Bracket - Receiver 8b 000001780 Top Bracket - Receiver 8c 6307214 Receiver Mounting Strap 9 000001290 Check Valve 10 000002883 Drier 11 Air Pumps 11a 000007222 Air Assist - 115V/60 Hz 11b 000007223 Air Assist - 230V/50-60 Hz 11c 4011739 Air Manifold [3] 11d 000006489 Air Assist Bracket 12 K00434 Luminlce 12a K00425 Luminlce Bulb 12b 000008283 Luminlce Wiring Harness 12c 000007990 Bulkhead Fitting 2.25" 12d 000008269 Bulkhead Fitting 2.75" 13 000008310 Thermistor with Spring Clips 14 8706093 Female Wing Adapter - 0.375" 15 1360961 Male Connector 16 8706083 Female Wing Adapter - 0.50" 17 000002340 Water Drain Tubing			•		<u></u> j
8b 000001780 Top Bracket - Receiver 8c 6307214 Receiver Mounting Strap 9 000001290 Check Valve 10 000002883 Drier 11 Air Pumps 11a 000007222 Air Assist - 115V/60 Hz 11b 000007223 Air Assist - 230V/50-60 Hz 11c 4011739 Air Manifold [3] 11d 000006489 Air Assist Bracket 12 K00434 LuminIce 12a K00425 LuminIce Bulb 12b 000008283 LuminIce Wiring Harness 12c 000007990 Bulkhead Fitting 2.25" 12d 000008269 Bulkhead Fitting 2.75" 13 000008310 Thermistor with Spring Clips 14 8706093 Female Wing Adapter - 0.375" 15 1360961 Male Connector 16 8706083 Female Wing Adapter - 0.50" 17 000002340 Water Drain Tubing					
8c 6307214 Receiver Mounting Strap 9 000001290 Check Valve 10 000002883 Drier 11 Air Pumps 11a 000007222 Air Assist - 115V/60 Hz 11b 000007223 Air Assist - 230V/50-60 Hz 11c 4011739 Air Manifold [3] 11d 000006489 Air Assist Bracket 12 K00434 LuminIce 12a K00425 LuminIce Bulb 12b 000008283 LuminIce Wiring Harness 12c 000007990 Bulkhead Fitting 2.25" 12d 000008269 Bulkhead Fitting 2.75" 13 000008310 Thermistor with Spring Clips 14 8706093 Female Wing Adapter - 0.375" 15 1360961 Male Connector 16 8706083 Female Wing Adapter - 0.50" 17 000002340 Water Drain Tubing					
9 000001290 Check Valve 10 000002883 Drier 11 Air Pumps 11a 000007222 Air Assist - 115V/60 Hz 11b 000007223 Air Assist - 230V/50-60 Hz 11c 4011739 Air Manifold [3] 11d 000006489 Air Assist Bracket 12 K00434 LuminIce 12a K00425 LuminIce Bulb 12b 000008283 LuminIce Wiring Harness 12c 000007990 Bulkhead Fitting 2.25" 12d 000008269 Bulkhead Fitting 2.75" 13 000008310 Thermistor with Spring Clips 14 8706093 Female Wing Adapter - 0.375" 15 1360961 Male Connector 16 8706083 Female Wing Adapter - 0.50" 17 000002340 Water Drain Tubing			·		
10 000002883 Drier 11 Air Pumps 11a 000007222 Air Assist - 115V/60 Hz 11b 000007223 Air Assist - 230V/50-60 Hz 11c 4011739 Air Manifold [3] 11d 000006489 Air Assist Bracket 12 K00434 LuminIce 12a K00425 LuminIce Bulb 12b 00008283 LuminIce Wiring Harness 12c 000007990 Bulkhead Fitting 2.25" 12d 000008269 Bulkhead Fitting 2.75" 13 000008310 Thermistor with Spring Clips 14 8706093 Female Wing Adapter - 0.375" 15 1360961 Male Connector 16 8706083 Female Wing Adapter - 0.50" 17 000002340 Water Drain Tubing					
111 Air Pumps 11a 000007222 Air Assist - 115V/60 Hz 11b 000007223 Air Assist - 230V/50-60 Hz 11c 4011739 Air Manifold [3] 11d 000006489 Air Assist Bracket 12 K00434 LuminIce 12a K00425 LuminIce Bulb 12b 000008283 LuminIce Wiring Harness 12c 000007990 Bulkhead Fitting 2.25" 12d 000008269 Bulkhead Fitting 2.75" 13 000008310 Thermistor with Spring Clips 14 8706093 Female Wing Adapter - 0.375" 15 1360961 Male Connector 16 8706083 Female Wing Adapter - 0.50" 17 000002340 Water Drain Tubing					
11a 000007222 Air Assist - 115V/60 Hz 11b 000007223 Air Assist - 230V/50-60 Hz 11c 4011739 Air Manifold [3] 11d 000006489 Air Assist Bracket 12 K00434 Luminlce 12a K00425 Luminlce Bulb 12b 000008283 Luminlce Wiring Harness 12c 000007990 Bulkhead Fitting 2.25" 12d 000008269 Bulkhead Fitting 2.75" 13 000008310 Thermistor with Spring Clips 14 8706093 Female Wing Adapter - 0.375" 15 1360961 Male Connector 16 8706083 Female Wing Adapter - 0.50" 17 000002340 Water Drain Tubing					
11b 000007223 Air Assist - 230V/50-60 Hz 11c 4011739 Air Manifold [3] 11d 000006489 Air Assist Bracket 12 K00434 LuminIce 12a K00425 LuminIce Bulb 12b 000008283 LuminIce Wiring Harness 12c 000007990 Bulkhead Fitting 2.25" 12d 000008269 Bulkhead Fitting 2.75" 13 000008310 Thermistor with Spring Clips 14 8706093 Female Wing Adapter - 0.375" 15 1360961 Male Connector 16 8706083 Female Wing Adapter - 0.50" 17 000002340 Water Drain Tubing		000007222	·		
11c 4011739 Air Manifold [3] 11d 000006489 Air Assist Bracket 12 K00434 LuminIce 12a K00425 LuminIce Bulb 12b 000008283 LuminIce Wiring Harness 12c 000007990 Bulkhead Fitting 2.25" 12d 000008269 Bulkhead Fitting 2.75" 13 000008310 Thermistor with Spring Clips 14 8706093 Female Wing Adapter - 0.375" 15 1360961 Male Connector 16 8706083 Female Wing Adapter - 0.50" 17 000002340 Water Drain Tubing					
11d 000006489 Air Assist Bracket 12 K00434 LuminIce 12a K00425 LuminIce Bulb 12b 000008283 LuminIce Wiring Harness 12c 000007990 Bulkhead Fitting 2.25" 12d 000008269 Bulkhead Fitting 2.75" 13 000008310 Thermistor with Spring Clips 14 8706093 Female Wing Adapter - 0.375" 15 1360961 Male Connector 16 8706083 Female Wing Adapter - 0.50" 17 000002340 Water Drain Tubing					[3]
12 K00434 LuminIce 12a K00425 LuminIce Bulb 12b 000008283 LuminIce Wiring Harness 12c 000007990 Bulkhead Fitting 2.25" 12d 000008269 Bulkhead Fitting 2.75" 13 000008310 Thermistor with Spring Clips 14 8706093 Female Wing Adapter - 0.375" 15 1360961 Male Connector 16 8706083 Female Wing Adapter - 0.50" 17 000002340 Water Drain Tubing					[0]
12a K00425 LuminIce Bulb 12b 000008283 LuminIce Wiring Harness 12c 000007990 Bulkhead Fitting 2.25" 12d 000008269 Bulkhead Fitting 2.75" 13 000008310 Thermistor with Spring Clips 14 8706093 Female Wing Adapter - 0.375" 15 1360961 Male Connector 16 8706083 Female Wing Adapter - 0.50" 17 000002340 Water Drain Tubing					
12b 000008283 LuminIce Wiring Harness 12c 000007990 Bulkhead Fitting 2.25" 12d 000008269 Bulkhead Fitting 2.75" 13 000008310 Thermistor with Spring Clips 14 8706093 Female Wing Adapter - 0.375" 15 1360961 Male Connector 16 8706083 Female Wing Adapter - 0.50" 17 000002340 Water Drain Tubing					
12c 000007990 Bulkhead Fitting 2.25" 12d 000008269 Bulkhead Fitting 2.75" 13 000008310 Thermistor with Spring Clips 14 8706093 Female Wing Adapter - 0.375" 15 1360961 Male Connector 16 8706083 Female Wing Adapter - 0.50" 17 000002340 Water Drain Tubing					
12d 000008269 Bulkhead Fitting 2.75" 13 000008310 Thermistor with Spring Clips 14 8706093 Female Wing Adapter - 0.375" 15 1360961 Male Connector 16 8706083 Female Wing Adapter - 0.50" 17 000002340 Water Drain Tubing					
13 000008310 Thermistor with Spring Clips 14 8706093 Female Wing Adapter - 0.375" 15 1360961 Male Connector 16 8706083 Female Wing Adapter - 0.50" 17 000002340 Water Drain Tubing			•		
14 8706093 Female Wing Adapter - 0.375" 15 1360961 Male Connector 16 8706083 Female Wing Adapter - 0.50" 17 000002340 Water Drain Tubing			•		
15					
16 8706083 Female Wing Adapter - 0.50" 17 000002340 Water Drain Tubing					
17 000002340 Water Drain Tubing					
Stop Storp S					
			•		



12176C REFRIGERATION COMPARTMENT - COMMON COMPONENTS

#	PART#	DESCRIPTION	QTY	Note
19	5650529	Clamp - Expansion Valve Bulb		
20	3000503	Strap - Expansion Valve Bulb - 0.5"		
21	5202069	Screw - #10-24 x 0.50" HEX		
22	4010439	Tubing - Water Inlet Valve		[4]
23	000002250	Mylar Shield - Water Inlet Valve		
24	4420291	Vinyl Tube - 0.25" OD		
25	4420883	Vinyl Tubing - 0.25" ID		
26	5000013	Thumbscrew - #8-32 x 0.375"		
27	000002466	Screw - #10-24 x 0.312"		[5]
28	4302643	Plug - 0.625"		

PART NOTES:

[1]	-	\pages from 000005156_02.jpg" width=280 height=256>
-----	---	---

[2] - \pages from \(\text{000005156} \) 02.jpg" width=266 height=183>


[3] - air pump tubing outlet

[4] - \pages from 401043_05.jpg" width=1797 height=2238>

[5] - Slot Hex



12176C HEAD SECTION - PANELS





12176C HEAD SECTION - PANELS


#	PART#	DESCRIPTION	QTY	Note
1	000008144	Left Side Panel		
2	000008146	Back Panel		
3	000008145	Right Side Panel		
4	000006699	Top Cover		
5	000010512	Front Door		
5a	000007599	Top Endcap		
5b	000007600	Bottom Endcap		
6	000010420	Coupling Panel		
7		Front Panel LCD Frame		
7a	000006647	LCD Frame with Key Guard		
7b	000006564	LCD Frame without Key Guard		
7c	K00433	Display Cover		[1]
8	000008023	Screw - #8-32 x 0.875"		
9	000007961	Top Front Rail		
9a	5202099	Screw - #10-24 x 0.50" PHIL		
9b	000002246	Plastic Dome Head Plug		
10	000007900	Front Panel Mounting Bracket		
10a	5026739	Mounting Screw 8-32 x 0.50 Phil		
11	000007838	Bottom Front Rail		
11a	5005099	Screw - #10-16 x 0.625"		
12		Front Posts		
12a	000008252	Front Post - Left		
12b	000008156	Front Post - Right		
13	5000373	Screw - #10-24 x 0.5" PHIL		
14	000002288	Spacer, Top Cover		
15	2006143	Terminal Block - 50 Hz - 3 Pole		
16		Electrical Connection Box Cover		
16a	000002230	Control Box		
16b	000002317	Electrical Connection Box Cover		
16c	5202069	Screw - #10-24 x 0.50" HEX		
17		Electrical Connection Box		
17a	6063989	Electrical Connection Box		
17b	000002316	Control Box		
18	7112429	Cartoning		

PART NOTES:

[1] - hides the display completely



ICVD2096 CONDENSING UNIT






ICVD2096 CONDENSING UNIT

#	PART#	DESCRIPTION	QTY	Note
1		Compressor		
1a	000011514	Compressor 208-230V/60 Hz/1 Ph		
1b	000008446	Compressor - Bristol - 208-230V/60 Hz/3 Ph		
2	8250473	Accumulator		
3	8373253	Access Valve		
4		Fan Motor		
4a	2000189	Fan Motor - 208-230V/60 Hz/1-3 Ph		
5	2002229	Low Pressure Cut-out		
6	8250083	Fan Blade		
7	8851413	Air Condenser		
8	000003190	Head Pressure Control Valve - 240 PSI		
9	8250559	Suction Line Filter		
9a	000006484	Suction Line Filter Bracket		
9b	000002210	Suction Line Filter Tie		
10	000002790	Fan Shroud		
11	3006833	Fan Motor Mounting Bracket		
11a	5033589	Mounting - Screw		
11b	5429559	Mounting - Rubber Wellnut		
12		Compressor Mounting		
12a	5035729	Mounting - Bolt		
12b	8503069	Mounting - Rubber Grommet		
12c	5573099	Mounting - Flatwasher		
12d	8503949	Mounting - Sleeve		
13	2512063	Strain Relief Bushing		
14	000001289	Check Valve		



ICVD2096 CONDENSING UNIT - CONTROL BOX



ICVD2096 CONDENSING UNIT - CONTROL BOX


#	PART#	DESCRIPTION	QTY	Note
1	2001263	Fan Cycling Control - 200-250 psig		[1]
2	2001243	HPCO		
3		Contactor		
3a	000007597	Contactor - 50-60 Hz/1 Ph - 24 Volt Coil		
3b	000007598	Contactor - 60 Hz/3 Ph - 24 Volt Coil		
4	000007581	Transformer		
5		Wiring Harness		
5a	000007741	Wiring Harness - 230V/60 Hz/1 Ph		
5b	000007747	Wiring Harness - 230V/60 Hz/3 Ph		
6		Terminal Block		
6a	000009929	Terminal Block - 60 Hz with Wiring Harness		
7	000005488	Run Capacitor - 115-230V/50-60 Hz/1 Ph		
8		Start Capacitor		
8a	8505823	Start Capacitor 50-60 Hz/1 Ph		
9		Start Relay		
9a	000007761	Start Potential Relay - 60 Hz/1 Ph		
10	5202069	Screw - #10-24 x 0.50" HEX		
11	6021601	Capacitor Mounting Strap		
12	6034981	Capacitor Mounting Bracket		
13	5202169	Screw - #10-24 x 0.50" Ground		
14	2500169	Bushing - 0.91" OD x 0.44" ID		
15	2500029	Bushing - 1.125" OD x 0.75" ID		

PART NOTES:

[1] - \pages from 200126_09.jpg" width=150 height=306>



ICVD2096 CONDENSING UNIT PANELS





ICVD2096 CONDENSING UNIT PANELS

#	PART#	DESCRIPTION	QTY	Note
1	3000143	Condenser Fan Guard		
2	6040171	Control Box Cover		
3	000006035	Control Box Panel		
4	000002144	Left Side Panel		
5	000002142	Top Cover		
6	6038741	Right Side Panel		
7	6042261	Condensing Unit Tube Shield		
8	5202069	Screw - #10-24 x 0.50" HEX		
9	000001025	Cartoning		

