


For more Parts Information: https://manitowocfsq.sysonline.com/Default.aspx

TABLE OF CONTENTS

Manitowoc Foodservice [Updated: Sep. 30, 2013]	
Manitowoc - Ice & Related	
Parts Catalog	
Ice Machine	
S Series	
S Model - Flake/Nugget	
SF0400, SN0450	
SF0400 SN0450 Control Box	
SF0400/SN0450 Evaporator Assembly	
SF0400/SN0450 Refrigeration Compartment	
SF0400/SN0450 Refrigeration Compartment Part 2	
SF0400/SN0450 Refrigeration Compartment - Air-cooled	
SF0400/SN0450 Refrigeration Compartment - Water-cooled	
SF0400/SN0450 Panels	



SF0400 SN0450 CONTROL BOX





SF0400 SN0450 CONTROL BOX


1	#	PART#	DESCRIPTION	QTY	Note
1a 4302253 Control Board Mounting Supports 1b 5202069 Screw - #10-24 x 0.50" HEX 2 2511493 10 Amp Fuse [1] 3 2007939 Toggle Switch 3a 2009973 Compressor to Control Board Wiring Harness 4 Contactor Contactor 4a 2006589 Contactor - 115V/60 Hz/1 Ph 5 Start Capacitor [2] 5a 3505773 Start Capacitor - 230V/50-60 Hz/1 Ph 5b 000000022 Start Capacitor - 230V/50-60 Hz/1 Ph 6a 000000029 Gearmotor Run Capacitor 230V/50-60 Hz/1 Ph 7 Start Relay [2] 7a 2002053 Start Potential Relay - 115V/60 Hz/1 Ph 7b 2002103 Start Potential Relay - 230V/50-60 Hz/1 Ph 8a Wiring Harness [1] 8a Wiring Harness 115V/60 Hz/1 ph 9 000000080 Start Capacitor Wiring Harness 10 2009963 Compressor to Control Board Wiring Harness 11 000002866 Control Box Cover [1] 12a 502069 Screw - #1	1	000001238	Control Board		
15	1a		Control Board Mounting Supports		
2 2511493 10 Amp Fuse [1] 3 2007939 Toggle Switch 3a 2009973 Compressor to Control Board Wiring Harness 4 Contactor 4a 2006589 Contactor - 115V/60 Hz/1 Ph 4b 2006599 Contactor - 230V/50-60 Hz/1 Ph 5 Start Capacitor [2] 5a 8505773 Start Capacitor - 230V/50-60 Hz/1 Ph 6 Run Capacitor - 230V/50-60 Hz/1 Ph 6a 000000029 Gearmotor Run Capacitor 230V/50-60 Hz/1 Ph 6b 000000029 Gearmotor Run Capacitor 230V/50-60 Hz/1 Ph 7 Start Relay [2] 7a 2002053 Start Potential Relay - 115V/60 Hz/1 Ph 7b 2002103 Start Potential Relay - 230V/50-60 Hz/1 Ph 8a 00001433 Wiring Harness [1] 8a 000001433 Wiring Harness 115V/60 Hz/1 ph 9 00000080 Start Capacitor Wiring Harness 10 2009963 Compressor to Control Board Wiring Harness 11 000002866 Control Box 12 00000034 Control Box Cover	1b	5202069	- ''		
3 2007939 Toggle Switch 3a 2009973 Compressor to Control Board Wiring Harness 4 Contactor 4a 2006589 Contactor - 230V/50-60 Hz/1 Ph 5 Start Capacitor [2] 5a 8505773 Start Capacitor - 115V/60 Hz/1 Ph 5b 000000022 Start Capacitor - 230V/50-60 Hz/1 Ph 6a 000000029 Gearmotor Run Capacitor 230V/50-60 Hz/1 Ph 6b 000000029 Gearmotor Run Capacitor 230V/50-60 Hz/1 Ph 7 Start Relay [2] 7a 2002053 Start Potential Relay - 115V/60 Hz/1 Ph 7b 2002103 Start Potential Relay - 230V/50-60 Hz/1 Ph 8a Wiring Harness [1] 8a 00001433 Wiring Harness 115V/60 Hz/1 ph 9 00000080 Start Capacitor Wiring Harness 10 2009943 Wiring Harness 230V/50 Hz/1 ph 9 00000034 Control Box Cover [1] 12 0000034 Control Box Cover [1] 12a 5202069 Screw - #10-24 x 0.50" HEX 13 6021601 Capac	2		10 Amp Fuse		[1]
3a 2009973 Compressor to Control Board Wiring Harness 4 Contactor 4a 2006589 Contactor - 230V/50-60 Hz/1 Ph 4b 2006599 Contactor - 230V/50-60 Hz/1 Ph 5 Start Capacitor [2] 5a 8505773 Start Capacitor - 115V/60 Hz/1 Ph 6b 000000022 Start Capacitor - 230V/50-60 Hz/1 Ph 6a 000000029 Gearmotor Run Capacitor 230V/50-60 Hz/1 Ph 6b 000000029 Gearmotor Run Capacitor 230V/50-60 Hz/1 Ph 7a Start Relay [2] 7a 2002053 Start Potential Relay - 115V/60 Hz/1 Ph 7b 2002103 Start Potential Relay - 230V/50-60 Hz/1 Ph 8a Wiring Harness [1] 8a 000001433 Wiring Harness 115V/60 Hz/1 ph 9 000000080 Start Capacitor Wiring Harness 10 2009963 Compressor to Control Board Wiring Harness 11 000002866 Control Box 12 000000934 Control Box Cover [1] 12a 5202069 Screw - #10-24 x 0.50" HEX 13 6021601	3	2007939	•		
44 Contactor 4a 2006589 Contactor - 115V/60 Hz/1 Ph 4b 2006599 Contactor - 230V/50-60 Hz/1 Ph 5 Start Capacitor [2] 5a 8505773 Start Capacitor - 115V/60 Hz/1 Ph 5b 000000022 Start Capacitor - 230V/50-60 Hz/1 Ph 6a 000000029 Gearmotor Run Capacitor 230V/50-60 Hz/1 Ph 6b 000000029 Gearmotor Run Capacitor 230V/50-60 Hz/1 Ph 7a Start Relay [2] 7a 2002053 Start Potential Relay - 115V/60 Hz/1 Ph 7b 2002103 Start Potential Relay - 230V/50-60 Hz/1 Ph 8 Wiring Harness [1] 8a 000001433 Wiring Harness 115V/60 Hz/1 ph 9 00000080 Start Capacitor Wiring Harness 10 2009963 Compressor to Control Board Wiring Harness 11 000002866 Control Box 12 000000934 Control Box Cover [1] 12a 5202069 Screw - #10-24 x 0.50" HEX 13 6021601 Capacitor Mounting Strap 14 5004129 Screw - #6 x 0.	3a	2009973			
4b 2006599 Contactor - 230V/50-60 Hz/1 Ph 5 Start Capacitor [2] 5a 8505773 Start Capacitor - 115V/60 Hz/1 Ph 5b 000000022 Start Capacitor - 230V/50-60 Hz/1 Ph 6 Run Capacitor [3] 6a 000000029 Gearmotor Run Capacitor 230V/50-60 Hz/1 Ph 7 Start Relay [2] 7a 2002053 Start Potential Relay - 115V/60 Hz/1 Ph 7b 2002103 Start Potential Relay - 230V/50-60 Hz/1 Ph 8 Wiring Harness [1] 8a 000001433 Wiring Harness 115V/60 Hz/1 ph 9 000000080 Wiring Harness 230V/50 Hz/1 ph 9 000000080 Start Capacitor Wiring Harness 10 2009963 Compressor to Control Board Wiring Harness 11 000002866 Control Box 12 00000934 Control Box Cover [1] 12a 5202069 Screw - #10-24 x 0.50" HEX 13 6021601 Capacitor Mounting Strap 14 5004129 Screw - #6 x 0.5" [4] 15 5202169 <t< td=""><td>4</td><td></td><td>•</td><td></td><td></td></t<>	4		•		
5 Start Capacitor [2] 5a 8505773 Start Capacitor - 115V/60 Hz/1 Ph 5b 000000022 Start Capacitor - 230V/50-60 Hz/1 Ph 6 Run Capacitor [3] 6a 000000029 Gearmotor Run Capacitor 230V/50-60 Hz/1 Ph 6b 000000029 Gearmotor Run Capacitor 230V/50-60 Hz/1 Ph 7 Start Relay [2] 7a 2002053 Start Potential Relay - 115V/60 Hz/1 Ph 8 Wiring Harness [1] 8a 00001433 Wiring Harness 115V/60 Hz/1 ph 9 00000080 Start Capacitor Wiring Harness 10 2009943 Wiring Harness 230V/50 Hz/1 ph 9 00000080 Start Capacitor Wiring Harness 11 00002866 Compressor to Control Board Wiring Harness 11 000002866 Control Box 12 00000934 Control Box Cover [1] 12a 5202069 Screw - #10-24 x 0.50" HEX 13 6021601 Capacitor Mounting Strap 14 5004129 Screw - #6 x 0.5" Ground	4a	2006589	Contactor - 115V/60 Hz/1 Ph		
5a 8505773 Start Capacitor - 115V/60 Hz/1 Ph 5b 000000022 Start Capacitor - 230V/50-60 Hz/1 Ph 6 Run Capacitor [3] 6a 000000029 Gearmotor Run Capacitor 230V/50-60 Hz/1 Ph 6b 000000029 Gearmotor Run Capacitor 230V/50-60 Hz/1 Ph 7 Start Relay [2] 7a 2002053 Start Potential Relay - 115V/60 Hz/1 Ph 7b 2002103 Start Potential Relay - 230V/50-60 Hz/1 Ph 8 Wiring Harness [1] 8a 000001433 Wiring Harness 115V/60 Hz/1 ph 9 000000080 Start Capacitor Wiring Harness 10 2009963 Compressor to Control Board Wiring Harness 11 000002866 Control Box 12 00000034 Control Box Cover [1] 12a 5202069 Screw - #10-24 x 0.50" HEX 13 6021601 Capacitor Mounting Strap 14 5004129 Screw - #6 x 0.5" Ground [4]	4b	2006599	Contactor - 230V/50-60 Hz/1 Ph		
5b 000000022 Start Capacitor - 230V/50-60 Hz/1 Ph 6 Run Capacitor [3] 6a 000000029 Gearmotor Run Capacitor 230V/50-60 Hz/1 Ph 6b 000000029 Gearmotor Run Capacitor 230V/50-60 Hz/1 Ph 7 Start Relay [2] 7a 2002053 Start Potential Relay - 115V/60 Hz/1 Ph 7b 2002103 Start Potential Relay - 230V/50-60 Hz/1 Ph 8 Wiring Harness [1] 8a 000001433 Wiring Harness 115V/60 Hz/1 ph 9 000000080 Start Capacitor Wiring Harness 10 2009963 Compressor to Control Board Wiring Harness 11 000002866 Control Box 12 000000934 Control Box Cover [1] 12a 520269 Screw - #10-24 x 0.50" HEX 13 6021601 Capacitor Mounting Strap 14 5004129 Screw - #6 x 0.5" Ground	5		Start Capacitor		[2]
66 Run Capacitor [3] 6a 000000029 Gearmotor Run Capacitor 230V/50-60 Hz/1 Ph 6b 000000029 Gearmotor Run Capacitor 230V/50-60 Hz/1 Ph 7 Start Relay [2] 7a 2002053 Start Potential Relay - 115V/60 Hz/1 Ph 7b 2002103 Start Potential Relay - 230V/50-60 Hz/1 Ph 8a Wiring Harness [1] 8a 000001433 Wiring Harness 115V/60 Hz/1 ph 9 00000080 Start Capacitor Wiring Harness 10 2009963 Compressor to Control Board Wiring Harness 11 000002866 Control Box 12 000000934 Control Box Cover [1] 12a 5202069 Screw - #10-24 x 0.50" HEX 13 6021601 Capacitor Mounting Strap 14 5004129 Screw - #6 x 0.5" [4] 15 5202169 Screw - #10-24 x 0.50" Ground	5a	8505773	Start Capacitor - 115V/60 Hz/1 Ph		
Gearmotor Run Capacitor 230V/50-60 Hz/1 Ph Gb 00000029 Gearmotor Run Capacitor 230V/50-60 Hz/1 Ph To Start Relay [2] Ta 2002053 Start Potential Relay - 115V/60 Hz/1 Ph Tb 2002103 Start Potential Relay - 230V/50-60 Hz/1 Ph Wiring Harness [1] 8a 000001433 Wiring Harness 115V/60 Hz/1 ph Bb 2009943 Wiring Harness 230V/50 Hz/1 ph 9 00000080 Start Capacitor Wiring Harness 10 2009963 Compressor to Control Board Wiring Harness 11 00002866 Control Box 12 00000934 Control Box Cover [1] 12a 5202069 Screw - #10-24 x 0.50" HEX 13 6021601 Capacitor Mounting Strap 14 5004129 Screw - #10-24 x 0.50" Ground	5b	000000022	Start Capacitor - 230V/50-60 Hz/1 Ph		
6b 000000029 Gearmotor Run Capacitor 230V/50-60 Hz/1 Ph 7 Start Relay [2] 7a 2002053 Start Potential Relay - 115V/60 Hz/1 Ph 7b 2002103 Start Potential Relay - 230V/50-60 Hz/1 Ph 8 Wiring Harness [1] 8a 000001433 Wiring Harness 115V/60 Hz/1 ph 8b 2009943 Wiring Harness 230V/50 Hz/1 ph 9 000000080 Start Capacitor Wiring Harness 10 2009963 Compressor to Control Board Wiring Harness 11 000002866 Control Box 12 000000934 Control Box Cover [1] 12a 5202069 Screw - #10-24 x 0.50" HEX 13 6021601 Capacitor Mounting Strap 14 5004129 Screw - #6 x 0.5" [4] 15 5202169 Screw - #10-24 x 0.50" Ground	6		Run Capacitor		[3]
7 Start Relay [2] 7a 2002053 Start Potential Relay - 115V/60 Hz/1 Ph 7b 2002103 Start Potential Relay - 230V/50-60 Hz/1 Ph 8 Wiring Harness [1] 8a 000001433 Wiring Harness 115V/60 Hz/1 ph 9 000000080 Start Capacitor Wiring Harness 10 2009963 Compressor to Control Board Wiring Harness 11 000002866 Control Box 12 00000934 Control Box Cover [1] 12a 5202069 Screw - #10-24 x 0.50" HEX 13 6021601 Capacitor Mounting Strap 14 5004129 Screw - #6 x 0.5" [4] 15 5202169 Screw - #10-24 x 0.50" Ground	6a	000000029	Gearmotor Run Capacitor 230V/50-60 Hz/1 Ph		
7a 2002053 Start Potential Relay - 115V/60 Hz/1 Ph 7b 2002103 Start Potential Relay - 230V/50-60 Hz/1 Ph 8 Wiring Harness [1] 8a 000001433 Wiring Harness 115V/60 Hz/1 ph 9 000000080 Start Capacitor Wiring Harness 10 2009963 Compressor to Control Board Wiring Harness 11 000002866 Control Box 12 000000934 Control Box Cover [1] 12a 5202069 Screw - #10-24 x 0.50" HEX 13 6021601 Capacitor Mounting Strap 14 5004129 Screw - #6 x 0.5" [4] 15 5202169 Screw - #10-24 x 0.50" Ground	6b	000000029	Gearmotor Run Capacitor 230V/50-60 Hz/1 Ph		
7b 2002103 Start Potential Relay - 230V/50-60 Hz/1 Ph 8 Wiring Harness [1] 8a 000001433 Wiring Harness 115V/60 Hz/1 ph 8b 2009943 Wiring Harness 230V/50 Hz/1 ph 9 000000080 Start Capacitor Wiring Harness 10 2009963 Compressor to Control Board Wiring Harness 11 000002866 Control Box 12 000000934 Control Box Cover [1] 12a 5202069 Screw - #10-24 x 0.50" HEX 13 6021601 Capacitor Mounting Strap 14 5004129 Screw - #6 x 0.5" [4] 15 5202169 Screw - #10-24 x 0.50" Ground	7		Start Relay		[2]
8 Wiring Harness [1] 8a 000001433 Wiring Harness 115V/60 Hz/1 ph 8b 2009943 Wiring Harness 230V/50 Hz/1 ph 9 000000080 Start Capacitor Wiring Harness 10 2009963 Compressor to Control Board Wiring Harness 11 000002866 Control Box 12 000000934 Control Box Cover [1] 12a 5202069 Screw - #10-24 x 0.50" HEX 13 6021601 Capacitor Mounting Strap 14 5004129 Screw - #6 x 0.5" [4] 15 5202169 Screw - #10-24 x 0.50" Ground	7a	2002053	Start Potential Relay - 115V/60 Hz/1 Ph		
8a 000001433 Wiring Harness 115V/60 Hz/1 ph 8b 2009943 Wiring Harness 230V/50 Hz/1 ph 9 000000080 Start Capacitor Wiring Harness 10 2009963 Compressor to Control Board Wiring Harness 11 000002866 Control Box 12 000000934 Control Box Cover [1] 12a 5202069 Screw - #10-24 x 0.50" HEX 13 6021601 Capacitor Mounting Strap 14 5004129 Screw - #6 x 0.5" [4] 15 5202169 Screw - #10-24 x 0.50" Ground	7b	2002103	Start Potential Relay - 230V/50-60 Hz/1 Ph		
8b 2009943 Wiring Harness 230V/50 Hz/1 ph 9 000000080 Start Capacitor Wiring Harness 10 2009963 Compressor to Control Board Wiring Harness 11 000002866 Control Box 12 00000934 Control Box Cover [1] 12a 5202069 Screw - #10-24 x 0.50" HEX 13 6021601 Capacitor Mounting Strap 14 5004129 Screw - #6 x 0.5" [4] 15 5202169 Screw - #10-24 x 0.50" Ground	8		Wiring Harness		[1]
9 00000080 Start Capacitor Wiring Harness 10 2009963 Compressor to Control Board Wiring Harness 11 000002866 Control Box 12 00000934 Control Box Cover [1] 12a 5202069 Screw - #10-24 x 0.50" HEX 13 6021601 Capacitor Mounting Strap 14 5004129 Screw - #6 x 0.5" [4] 15 5202169 Screw - #10-24 x 0.50" Ground	8a	000001433	Wiring Harness 115V/60 Hz/1 ph		
10 2009963 Compressor to Control Board Wiring Harness 11 000002866 Control Box 12 000000934 Control Box Cover [1] 12a 5202069 Screw - #10-24 x 0.50" HEX 13 6021601 Capacitor Mounting Strap 14 5004129 Screw - #6 x 0.5" [4] 15 5202169 Screw - #10-24 x 0.50" Ground	8b	2009943	Wiring Harness 230V/50 Hz/1 ph		
11 000002866 Control Box 12 000000934 Control Box Cover [1] 12a 5202069 Screw - #10-24 x 0.50" HEX 13 6021601 Capacitor Mounting Strap 14 5004129 Screw - #6 x 0.5" [4] 15 5202169 Screw - #10-24 x 0.50" Ground	9	08000000	Start Capacitor Wiring Harness		
12 000000934 Control Box Cover [1] 12a 5202069 Screw - #10-24 x 0.50" HEX 13 6021601 Capacitor Mounting Strap 14 5004129 Screw - #6 x 0.5" [4] 15 5202169 Screw - #10-24 x 0.50" Ground	10	2009963	Compressor to Control Board Wiring Harness		
12a 5202069 Screw - #10-24 x 0.50" HEX 13 6021601 Capacitor Mounting Strap 14 5004129 Screw - #6 x 0.5" [4] 15 5202169 Screw - #10-24 x 0.50" Ground	11	000002866	Control Box		
13 6021601 Capacitor Mounting Strap 14 5004129 Screw - #6 x 0.5" [4] 15 5202169 Screw - #10-24 x 0.50" Ground	12	000000934	Control Box Cover		[1]
14 5004129 Screw - #6 x 0.5" [4] 15 5202169 Screw - #10-24 x 0.50" Ground	12a	5202069	Screw - #10-24 x 0.50" HEX		
15 Screw - #10-24 x 0.50" Ground	13		- · · · · · · · · · · · · · · · · · · ·		
	14		Screw - #6 x 0.5"		[4]
16 Bushings	15	5202169	Screw - #10-24 x 0.50" Ground		
	16		Bushings		


PART NOTES:

[1]	-	Not shown
[2]	-	Compresso
[3]	-	Gearmotor
[4]	_	10-24 x 3/8



SF0400/SN0450 EVAPORATOR ASSEMBLY





SF0400/SN0450 EVAPORATOR ASSEMBLY

#	PART#	DESCRIPTION	QTY	Note
1		Evaporator Assembly		
1a	3006743	Nugget		
1b	000000482	Flake		
2	000002945	Evaporator Foundation		
3	000003060	Coupler		
4		Gear Motor Assembly		
4a	000002088	Gearmotor Assembly - 50 Hz		
4b	2009553	Gearmotor Assembly - 60 Hz		
5	000006516	Float Chamber Assembly		[1]
5a	2008633	Float Switch Only		
5b	000006515	Float Chamber Only		
6	5650729	Compression Nut		
7	6072531	Float Valve Bracket		
7a	5202069	Screw - #10-24 x 0.50" HEX		
8	6071881	Gearmotor Bracket		
8a	5000293	Screw		
9		Evaporator Mounting to Gear Motor		
9a	5000273	Bolt		
9b	5573049	Flatwasher		
9c	5545119	Mounting - Lockwasher		
9d	5000269	Screw		
9e	5006203	O-ring		
10	000000464	Clamp Assembly		[2]


PART NOTES:

[1] - includes float, switch, cover & housing

[2] - secures evaporator to ice chute



SF0400/SN0450 REFRIGERATION COMPARTMENT





SF0400/SN0450 REFRIGERATION COMPARTMENT

#	PART#	DESCRIPTION	QTY	Note
1		Compressor		
1a	7601363	Compressor - Danfoss - 115V/60 Hz/1 Ph		
1b	7601373	Compressor - Danfoss - 230V/50 Hz/1 Ph		
1c	8251403	Overload - 115V/60 Hz/1 Ph		
2		Water Dump Valve		
2a	000007429	Water Dump Valve 115V		
2b	000007428	Water Dump Valve 208-240V		
3	000000935	Expansion Valve		
4	4000403	Valve Insulation Boot - Body		
5	4007203	Valve Insulation Boot - Bulb		[1]
5a	3000833	Strap - Expansion Valve Bulb - 0.375"		
5b	5650529	Clamp - Expansion Valve Bulb		
6		Liquid Line Solenoid Valve		
6a	7630021	Solenoid Valve 115V		
6b	7630081	Solenoid Valve 208-230V		
7		Liquid Line Solenoid Coil		
7a	000005156	Danfoss Solenoid Valve Coil Only - 115V/60 Hz		[2]
7b	000005157	Danfoss Solenoid Valve Coil Only - 230V/50-60 Hz		[3]
8	2001243	High Pressure Cut-out Control		
9	8310233	Manifold Strainer		
10	8930259	Drier		
11	8373253	Access Valve		
12	6071891	Compressor Base		
12a	5012319	Screw - #12-16 x 0.75"		
13		Compressor Mounting		
13a	5000899	Compressor Rubber Grommet		
13b	5000939	Screw		
13c	5000909	Sleeve		
13d	5000979	Washer		
14	8706093	Female Wing Adapter - 0.375"		
14a	5202069	Screw - #10-24 x 0.50" HEX		
15	1360961	Male Connector		
16		Water Inlet Tubing 1/4"		[4]
17	6042901	Water Inlet Tubing Insulation		[5]
18	80000000	Water Dump Valve Guard		
18a	5202329	Screw - #10-24 x 0.25" PH		


PART NOTES:

[1]	- \pages from 400720_08.jpg" width=923 height=583>
[2]	- \pages from 000005156_02.jpg" width=280 height=256>
[3]	- \pages from 000005156_02.jpg" width=266 height=183>
[4]	- No Longer AvailableNot shown

[5] - Not shown



SF0400/SN0450 REFRIGERATION COMPARTMENT PART 2





SF0400/SN0450 REFRIGERATION COMPARTMENT PART 2

#	PART#	DESCRIPTION	QTY	Note
1	2009793	Hall Effect Switch with Wiring		
2	2009803	Hall Effect Switch Housing		
2a	5121629	Screw		
3	5650853	Receptacle		
3a	5000453	Wing-head Mounting Stud		
4		Damper Door		
4a	4014443	Damper Door Nugget		
4b	00000710	Damper Door Flake		
5	4013363	Ice Chute		
6	4014883	Strainer Ramp		
7	4013463	Chute Cover - sits on receptacle		
8		Ice Wiper		
8a	000002062	Ice Wiper - Nugget		
8b	000000485	Ice Wiper - Flake		
9	4015753	Ice Tube Base		[1]
10	4015663	Ice Chute/Ice Tube Union		
11		Secure Ice Chute to Evaporator		
11a	000000464	Clamp Assembly		
12		Molded Vinyl Tubes		
12a	00000003	Float Chamber Tube		
12b	00000007	Drain		
12c	00000009	Elbow		[2]
12d	00000005	Ice Chute Drain Tube		
13		Snap Clamps		
13a	5650539	Snap Clamp - 1.123 x 1.296		
13b	5650709	Snap Clamp - 0.799"/0.899" ID		
13c	5650993	Snap Clamp - 3/4" ID		
13d	5650649	Hose Clamp - 0.759"/0.848" ID		


PART NOTES:

[1] - Discontinued

[2] - connects Float Chamber Tube to Ice Chute Drain Tube



SF0400/SN0450 REFRIGERATION COMPARTMENT - AIR-COOLED





SF0400/SN0450 REFRIGERATION COMPARTMENT - AIR-COOLED


#	PART#	DESCRIPTION	QTY	Note
1		Compressor		[1]
2	8252843	Air Condenser		[-]
3	2416223	Fan Blade		
4		Fan Motor		
4a	2000223	Fan Motor - 115V/60 Hz/1 Ph		
4b	2000219	Fan Motor - 208-230V/50-60 Hz		
5	4015323	Air Baffle		
6	4040103	Air Filter		
7	6073101	Fan Shroud		
8	5005513	Screw 0.7 x 8 mm		
9	5202069	Screw - #10-24 x 0.50" HEX		
10	000000287	Fan Motor Bracket		
11	5650699	Air Filter Clip		
12		Back Corner Channel		
12a	6072321	Back Corner Channel Right		
12b	6072311	Back Corner Channel Left		

PART NOTES:

[1] - Refer to COMMON PARTS PAGE



SF0400/SN0450 REFRIGERATION COMPARTMENT - WATER-COOLED



SF0400/SN0450 REFRIGERATION COMPARTMENT - WATER-COOLED


#	PART#	DESCRIPTION	QTY	Note
1		Compressor		[1]
2	000008892	Receiver		
3	8865323	Water-Cooled Condenser		
4	8372069	Water Regulating Valve		
5	8706103	Female Wing Adapter - 0.50"		
6	6000541	Receiver Strap		
7	5202069	Screw - #10-24 x 0.50" HEX		
8	5573419	Washer		
9	000000125	Water Condenser Bracket		
10		Back Corner Channel		
10a	6072361	Back Corner Channel Right		
10b	6072311	Back Corner Channel Left		

PART NOTES:

[1] - Refer to COMMON PARTS Page



SF0400/SN0450 PANELS



SF0400/SN0450 PANELS

#	PART#	DESCRIPTION	QTY	Note
1	6072601	Front Panel		
2	6060541	Right Side Panel		
3	6060551	Left Side Panel		
4	6072571	Back Panel, Water		
5	4012029	Top Cover		
6	4015323	Air Baffle		
7	4040103	Air Filter		
8	000000260	Front Panel - Shoulder Bolt		
8a	000000305	Front Panel - Nut		
9	5650699	Air Filter Clip		
10	000000263	Top Cover Bracket		
11	00000010	Top Front Bracket		
12	6072561	Top Support Brace		
13	000002867	Front Corner Channel		
13a	5012319	Screw - #12-16 x 0.75"		
14	6072371	Top Channel		
14a	5202069	Screw - #10-24 x 0.50" HEX		
15		Back Panel		
15a	5012319	Screw - #12-16 x 0.75"		
15b	5202099	Screw - #10-24 x 0.50" PHIL		
16	6067299	Rear Connection Box Cover		
17	6067289	Rear Connection Box		
17a	2006143	Terminal Block - 50 Hz - 3 Pole		
17b	2008503	Ground Wire		
17c	5202169	Screw - #10-24 x 0.50" Ground		
18	7112389	Cartoning		

