

Parts List

Modular Crescent Cuber

Models KM-1340MAH, MWH, MRH/3



Number: 71251 Issued: 5-1-2006 Revised: 9-7-2016

CONTENTS

Auxiliary Codes	. 3
Note About Ordering Parts	
A. Main Assembly & Refrigeration Circuit	
KM-1340MAH	
KM-1340MWH	. 7
KM-1340MRH	
B. Water Circuit	11
C. Control Box Assembly	14
D. Accessories & Labels	

Auxiliary Codes

KM-1340MAH

Q-0 October 2005 R-0 February 2006 September 2006 R-1 S-1 January 2007 T-0 January 2008 U-0 January 2009 U-1 August 2009 V-0 January 2010 V-1 July 2010 A-0 January 2011 A-1 September 2011 B-0 January 2012 C-0 January 2013 D-0 January 2014 D-1 November 2014 E-0 January 2015 E-1 February 2015 F-0 January 2016

KM-1340MWH

- Q-0 October 2005 R-0 February 2006 R-1 August 2006 S-1 January 2007 T-0 January 2008 U-0 January 2009 U-1 August 2009 V-0 January 2010 July 2010 V-1 A-0 January 2011 A-1 September 2011 B-0 January 2012
- C-0 January 2013 C-1 May 2013 D-0 January 2014 D-1 November 2014 E-0 January 2015 E-1 February 2015

January 2016

F-0

KM-1340MRH

Q-0 October 2005 R-0 February 2006 R-1 August 2006 S-1 January 2007 T-0 January 2008 U-0 January 2009 U-1 August 2009 V-0 January 2010 V-1 July 2010 A-0 January 2011 A-1 September 2011 B-0 January 2012 C-0 January 2013 D-0 January 2014 D-1 June 2014 D-2 November 2014 E-0 January 2015 F-0 January 2016

KM-1340MRH3

E-0 March 2015 F-0 May 2016


Auxiliary Code Breakdown

The auxiliary code is the first two characters in the serial number. The first character indicates the year. Years progress or regress in alphabetical order. The series runs from "A" through "V" and the letters "I" and "O" are skipped. The second character indicates significant part changes within a year. Base is "0" and this number advances for each change. In cases where there is a letter in parentheses, this designates the month. This is the last character in the serial number. The series runs from "(A)" through "(M)" and the letter "(I)" is skipped. This designation is only included when identifying a parts change within an auxiliary code.

Note About Ordering Parts


Most assemblies cannot be ordered as complete units; parts in the assemblies generally must be ordered separately.

A. Main Assembly & Refrigeration Circuit KM-1340MAH




Title: A	Main Assembly & Refrigeration	n Circuit Mo	del: KM-1340N	/IAH								
	, ,						Requi	red N	umber			
				Q-0	U-1	A-1						
Index		Material or		to	to	to						
No.	Description	Model Number		U-0	A-0	F-0						\Box
	Te	IM:	ain Assembly					i	1	1		
1	Front Panel	1 700	2A2164-01	1	1	1						
2	Gasket	L=762 mm	4A0808L02	1	1	1			-	-		_
3	Top Panel		2A8088-01	1	1	1			-	-	-	
4	Right Side Panel		2A2165G01	1	1	1			-	-		
5	Front Insulation		322711G01	1	1	1						
6	Top Insulation		322714G01	1	1	1			-	-	_	\vdash
7	Control Box Cover	1	3A2386-01	1	1	1						\vdash
8	Junction Box Cover	<u> </u>	433410-01	1	1	1			-	-		
9	Louver		1A0547-01	3	3	3						
9a	Push Retainer		4A2414-01	9	9	9						
10	Air Filter		2A2062G01	3	3	3						$oxed{oxed}$
11	Bulb Holder Bracket		322815G02	1	1	1						
11a	Thumbscrew		415949G10	2	2	2						
12	Bulb Holder		3A3903-01	1	1	1						igsquare
13	Capillary Ring		425307-02	1	1	1						Щ
	T	Refri	geration Circ					i	1	1		
14	Compressor		4A1412-01	1	1	-						
			4A1412-03			1						\sqcup
15	Condenser		1A1093-01	1	1	1						Ш
16	Evaporator Assembly (includes item 17)		104442G03	1	1	1						
17	Evaporator Plate		103317G01	4	4	4						
18	Thermostatic Expansion Valve		4A1482-01	2	2	2						
19	Thermostatic Expansion Valve Cover		3A0944-01	2	2	2						
20	Thermostatic Expansion Valve Bulb Holder		3A0107-01	2	2	2						
21	Hot Gas Valve Body		4A3978-01	1	1	1						
22	Liquid Line Valve Body		4A3276-01	1	1	1						
23	Valve Coil		4A3277-01	2	2	2						
24	Check Valve		4A1373-01	2	2	2						
25	Strainer		441569-02	1	1	1						
26	High-Pressure Switch		433441-07	1	-							
			463180-04		1	1						
27	Thermistor		429006-03	1	1	1						
28	Thermistor Holder		427430-01	1	1	1						
29	Fan Motor		4A3158-01	2	2	2						
30	Fan Motor Capacitor	5MFD, 250VAC	443192-02	2	2	2						
31	Fan Blade		444898-01	2	2	2						
32	Drier		4A2666-01	1	1	1						

A. Main Assembly & Refrigeration Circuit KM-1340MWH




Title: A		n Circuit Mo	del: KM-1340N	/WH								
							Requi	red N	umber			
				Q-0	U-1	A-1	C-1					
Index		Material or		to	to	to	to					
No.	Description	Model Number		U-0	A-0	C-0	F-0					
		Ma	ain Assembly									
1	Front Panel		2A2164-02	1	1	1	1					
2	Gasket	L=762 mm	4A0808L02	1	1	1	1					
3	Top Panel		2A8088-01	1	1	1	1					
4	Right Side Panel		2A2165G01	1	1	1	1					
5	Front Insulation		322711G01	1	1	1	1					
6	Top Insulation		322714G01	1	1	1	1					
7	Control Box Cover		3A2386-01	1	1	1	1					
8	Junction Box Cover		433410-01	1	1	1	1					
9	Bulb Holder Bracket		322815G02	1	1	1	1					
9a	Thumbscrew		415949G10	2	2	2	2					
10	Bulb Holder		3A3903-01	1	1	1	1					
11	Capillary Ring		425307-02	1	1	1	1					
Refrigeration Circuit												
12	Compressor		4A1412-01	1	1	-						
			4A1412-03			1	1					
13	Condenser		2A2359G04	1	1	1	-					
			3A7236-01				1					
14	Water Regulating Valve		4A0911-07	1	1	1	1					
15	Male Connector		4A1087-01	1	1	1	1					
16	Evaporator Assembly (includes item 17)		104442G03	1	1	1	1					
17	Evaporator Plate		103317G01	4	4	4	4					
18	Thermostatic Expansion Valve		4A1482-01	2	2	2	2					
19	Thermostatic Expansion Valve Cover		3A0944-01	2	2	2	2					
20	Thermostatic Expansion Valve Bulb Holder		3A0107-01	2	2	2	2					
21	Hot Gas Valve Body		4A3978-01	1	1	1	1					
22	Liquid Line Valve Body		4A3276-01	1	1	1	1					
23	Valve Coil		4A3277-01	2	2	2	2					
24	Check Valve		4A1373-01	2	2	2	2					
25	Strainer		441569-02	1	1	1	1					
26	High-Pressure Switch		433441-05	1	-							
			463180-05		1	1	1					
27	Thermistor		429006-03	1	1	1	1					
28	Thermistor Holder		427430-01	1	1	1	1					
29	Drier		4A2666-01	1	1	1	1					

A. Main Assembly & Refrigeration Circuit KM-1340MRH/3



							Requi	red N	umber			
				Q-0	U-1	A-1						Т
Index		Material or		to	to	to	E-0					
No.	Description	Model Number		U-0	A-0	D-2	F-0				<u></u>	L
	T=	Ma	in Assembly									_
1	Front Panel		2A2164-02	1	1	1	1		<u> </u>	_	 	╄
2	Gasket	L=762 mm	4A0808L02	1	1	1	1				├──	╄
3	Top Panel		2A2163-01	1	1	1	1				├──	\vdash
4	Right Side Panel		2A2165G01	1	1	1	1			-	<u> </u>	╀
5	Front Insulation		322711G01	1	1	1	1				├──	╀
6	Top Insulation		322714G01	1	1	1	1				├──	╀
7	Control Box Cover		3A2386-01	1	1	1	1				├──	╄
8	Junction Box Cover		433410-01	2	2	2	2		ļ		├──	╄
9	Bulb Holder Bracket		322815G02	1	1	1	1		-	_	 	\vdash
9a	Thumbscrew		415949G10	2	2	2	2		-	<u> </u>	—	\vdash
10	Bulb Holder		3A3903-01	1	1	1	1				├──	\vdash
11	Capillary Ring		425307-02	1	1	1	1				Ļ—	╄
12	Main Transformer	KM-1340MRH3	4A5695-01				1					
		Defei										
-10	I 0	Retriç	geration Circu		_				1	1		$\overline{}$
13	Compressor (A-1 and later utilize external		4A1412-02	1	1	-					 	╀
	crankcase heater - item 14)	IAN 40 40 NEDITO	4A1412-03			1	1				├──	╀
4.4	,	KM-1340MRH3		4	4	4	1			-	├──	╀
14	Receiver		437652-01	1	1	1	1				 	╀
15	Crankcase Heater		4A5397-02	1	1	1	1				 	╀
16	Evaporator Assembly (includes item 17)		104442G03	1	1	1	1					L
17	Evaporator Plate		103317G01	4	4	4	4					<u> </u>
18	Thermostatic Expansion Valve		4A1482-01	2	2	2	2					
19	Thermostatic Expansion Valve Cover		3A0944-01	2	2	2	2					
20	Thermostatic Expansion Valve Bulb Holder		3A0107-01	2	2	2	2					Γ
21	Hot Gas Valve Body		4A3978-01		1	1	1					Т
22	Liquid Line Valve Body		4A3276-01		1	1	1					П
23	Valve Coil		4A3277-01	2	2	2	2					
24	Check Valve		4A1373-01	2	2	2	2					Г
25	Strainer		441569-02	1	1	1	1					Г
26	High-Pressure Switch		433441-07	1	-							Г
			463180-04		1	1	1					Т
27	Thermistor		429006-03	1	1	1	1					Т
28	Thermistor Holder		427430-01	1	1	1	1					Т
29	Drier		4A2666-01	1	1	1	1					Т
30	Discharge Line Coupling		434136G01	1	1	1	1					Г
31	Liquid Line Coupling		4A3887G01	1	1	1	1					T


B. Water Circuit KM-1340M_H/3



Title: B	. Water Circuit Model: KM-13	40M_H/3								
						Requi	red N	umber		
				Q-0						
Index	Description	Material or	Dowt Niversity	to						
No.	Description Pump Motor Assembly	Model Number S-0731		F-0	<u> </u>			-		
1	Pump Motor Assembly (includes items 2 through 9a)	5-0/31	215693A01	1						
2	Pump Motor		3A7682-01	1						
3	Pump Flange		215662-01	1						
3a	Hex Head Bolt	6x40, SS	7B02-0640	4						
3b	Tooth Washer	M6, SS	7R22-0600	1						
3с	Hex Nut	M6, SS	7N12-0600	4						
3d	Split Lock Washer	M6, SS	7L22-0600	4						
Зе	Flat Washer	M6, SS	7W22-0600	4						
4	Mechanical Seal		4A3820-01	1						
5	Packing		428547-01	1						
6	Impeller		428548-01	1						
7	Pin	SS	4A0648-01	1						
8	Pump Housing		212636-01	1						
8a	Hexagon Bolt	4×30, SS	7B02-0430	4						
8b	Hex Flange Nut	M4, SS	7J02-0400	4						
9	Pump Motor Bracket		435057-01	1						
10	Water Supply Pipe		4A5216G04	1						
11	Rubber Gasket		413854-03	1		 				
12	Inlet Water Valve		3U0111-02	1						
13	Left Water Supply Tube		2A0079-01	1						
14	Right Water Supply Tube		2A0079-02	1						
15	Vinyl Hose	L=58 mm	7716-1519	1						
16	Vinyl Hose	L=63 mm	7716-2025	2						
17	Left Spray Tube		1A0260-02	1						
18	Right Spray Tube		1A0260-01	1						
19	Spray Guide		208586-01	12						
20	Plug		4A0176-01	4						
21	Cube Guide A		214905-01	1		 				
21a	Thumbscrew		415949G12	1			 			
22	Cube Guide B		322644-02	1						
23	Plate		3A0133-01	1			 			
24	Collar		435269-01	2		 				
25	Drain Hose Inlet Hose A		435092-01	1	<u> </u> 					
26			435091-01	1	<u> </u>					
27	Distributor Tee		432426-01	1			 			
28	Distibutor A (Tee)		4A0177-01	1		 				
29	Distributor B (Tee) Float Switch		432426-01 4A3624-02	2	 		 			
30 31	Float Switch Connector		426799-01	1	<u> </u>					
32	Upper Drain Valve Housing		3A1170-01	1						
33	O-Ring		7611-G035	1			 			
34	Valve Seat		433705-01	1			<u> </u>			
35	Spring Spring		322685-01	1		 <u> </u>	 			
36	Lower Drain Valve Housing		435054-01	1						
37	Distributor Hose (C)		326655-01	1						
38	Overflow Cap		322816-01	1						
39	Overflow Pipe		322691-01	1						
40	O-Ring		4A1234-01	1						
40	U-ning		4A 1234-UI							


Title: B	. Water Circuit Model: KM-13	340M_H/3										
				Required Number								
				Q-0								
Index		Material or		to								1
No.	Description	Model Number		F-0								
41	Cleaning Valve Handle		215383-01	1							<u> </u>	
42	Cleaning Valve Microswitch		4A2546-01	1								
43	Cleaning Valve Ball Valve		439293-01	1								
44	Cleaning Valve Male Adaptor		325826-01	2								
45	Bypass Hose		439265-01	1								
46	Rubber Ring		439236-01	1								
47	Corner Insulation (A)		439376-01	1								
48	Corner Insulation (B)		439392-01	1								
49	Flange		439267-01	1								
50	Silicone Hose	L=80 mm	7730 3812	1								
51	Silicone Hose	L=130 mm	7730 3812	2								
52	Spring		435825-01	1								
53	Connector		432763-01	1						İ	ĺ	
54	Vinyl Hose	L=190 mm	7716-2025	1								
55	Vinyl Hose	L=670 mm	7716-2025	1								
56	Holder		322692-01	1								
57	Vinyl Hose	L=30 mm	7716-2025	1						İ		
		Н	ose Clamps									
	Hose Clamp	18 mm	427443-05	4								
		25 mm	427443-03	11								
		27 mm	427443-08	2								

C. Control Box Assembly KM-1340M_H/3



Title: C	Control Box Assembly Mod	del: KM-1340M_	H/3								
							Requ	ired N	umber		
				Q-0		E-1					
Index		Material or		to		to					
No.	Description	Model Number		D-0	D-1	F-0					
1	Start Capacitor	145-174MFD, 250VAC	3A0076-01	1	1	1					
2	Run Capacitor	35MFD, 370VAC	3A2005-05	1	1	1					
3	Start Relay		4A1107-09	1	1	1					
4	Compressor Relay	KM-1340MAH KM-1340MWH	4A3140-01	1	1	1					
		KM-1340MRH	4A5096-01	1	-						
			4A3140-01		1	1					
5	Pump Motor Capacitor	10MFD, 250VAC	443192-01	1	1	1					
6	Control Transformer		3A0172-01	1	1	1					
7	"E" Control Board	KM-1340MAH KM-1340MWH	2A1410-01	1	1	-					
		KM-1340MRH		1	-						
	"G" Control Board	KM-1340MAH KM-1340MWH	2A3792-01		1	1					
		KM-1340MRH			1	1					
7a	Control Board Support		4A0336-03	4	4	4					
8	K4 Jumper		4A4883G01		1	1					
9	Control Switch		443119-01	1	1	1					
10	Fuse Holder (control)		4A5443-01	1	1	1					
11	Fuse (control)	AGC-10A, 250VAC	4A0893-07	1	1	1					
12	Bin Control Thermostat		4A2879-02	1	1	1					
13	Crankcase Heater Relay	KM-1340MRH	406132-07		1	1					

D. Accessories & Labels KM-1340M_H/3



Title: D	Title: D. Accessories & Labels Model: KM-1340M_H/3													
				Required Number										
				Q-0										
Index		Material or		to										
No.	Description	Model Number	Part Number	F-0										
1	Hoshizaki Emblem Label		4A0560-01	1										
2	Penguin Label		4A0526-01	1										
3	Universal Brace		4A0363-01	2										
3a	Hex Head Bolt		7B02-0512	2										