This parts list contains the parts for the MCM1062R. The model number of the machine is located on the ice machine in two places: on the back panel, and behind the front panel below the control box.


Check the model number to be certain of obtaining the correct parts.

TABLE OF CONTENTS

Cabinet	age 2
Refrigeration System	⊃age 3
Water System	⊃age 4
Control Box	⊃age 5
Remote Condenser	⊃age 6
MDB560 Ice Storage Bin	⊃age 7
MDB550 Ice Storage Bin	⊃age 8
Wiring Diagrams	⊃age 9


CABINET

ITEM	PART		ITEM	PART	
NUMBER	NUMBER	DESCRIPTION	NUMBER	NUMBER	DESCRIPTION
1	A32159-002	Top Panel, SS	12	A31462-001	Tube bracket
2	02-2887-02	Right Liner	13	A34908-021	Transducer
3	A35453-002	Right Side Panel, SS	14	02-0836-00	Catch
4	A32470-001	Brace	15	A34038-002	Service Panel
5	A32469-001	Upper cabinet brace	16	03-1404-12	Screw
6	03-1531-01	Screw	17	A32435-002	Left Side Panel
7	A34862-002	Front Panel SS	18	A34861-001	Base Assembly
	15-0411-00	Strike for front panel	19	A32454-001	Retainer
	03-1406-04	Nut for strike	20	A34826-002	Back Panel SS
8	A32549-002	Flange retainer	21	A32452-002	Right Back Panel SS
9	A32587-001	Upper Evap. Brace	22	02-2888-02	Back Liner
10	A32467-001	Lower Evap. Brace	23	A32464-001	Curtain Stand Off
11	02-2885-02	Left liner			




REFRIGERATION SYSTEM					
ITEM	PART		ITEM	PART	
NUMBER	NUMBER	DESCRIPTION	NUMBER	NUMBER	DESCRIPTION
1	16-0876-01	Evap. inlet assembly	8	12-2274-01	Liquid line valve
2	A30296-020	Evaporator	9	02-3319-02	Filter dryer
3	11-0446-24	Hi pressure control switch	10	16-0761-01	Receiver
4	16-0560-00	Valve core	11	16-0850-03	3/8" male coupling
	16-0563-00	Сар	12	16-0850-01	1/2" male coupling
5	16-0801-22	Accumulator	13	11-0422-23	Head press. control valve
6	11-0467-22	Pump down control switch	14	12-2428-22	Hot gas valve
7	18-8862-22	Compressor 203-230/60/3		02-3231-02	Hot gas valve filter
		CRG3-0250-TF5-270	15	12-2300-02	Hi temp cut out
	12-2308-01	Crankcase heater	16	16-0816-22	Thermo expansion valve
	18-2200-27	Sleeve		02-2920-01	Insulation for TXV (half)
	18-2200-28	Grommet		02 2020 0.	
	03-1405-20	Screw			
	03-1403-20	Sciew		6	1
				/	
. 12		13 14			
		13 14 15			
11		\ \ \ \ \			3
		\ \			8
		\ \	٠.		
Q .					İ
					fi.
10				A Page	
\		16			
6					2
Ų					
			」		
	9	17	ΨŲŲΫ		
		j			
9			Y		
٠ . L				6	_ 3
					4
		•		4.	
			i l	E	

WATER SYSTEM




November 2005 Page 4

MCM1062R SERVICE PARTS CONTROL BOX




ITEM	PART	
NUMBER	NUMBER	DESCRIPTION
1	12-0739-02	Contactor 3 phase
2	12-2317-22	Timer and microswitch
3	A34880-001	Cover plate
4	12-2375-01	ON/OFF/WASH switch
5	02-3126-01	Knob
6	03-1638-03	Screw
7	12-2400-01	Selector switch, connects to item 9
8	12-1879-03	Relay
9	12-2376-21	Bin level control board
10	no number	Knob for cube size control, part of item 11
11	11-0436-21	Cube size control, includes knob
12	02-2242-02	Stand off
13	12-1912-01	Circuit board
14	12-0426-01	Compressor on off switch
15	12-2285-22	Transformer
Not Shown:		
16	A34845-001	Control Box Cover

MCM1062R SERVICE PARTS SCOTSMAN REMOTE CONDENSER




RC1052		
ITEM	PART	
NUMBER	NUMBER	DESCRIPTION
1	02-2628-01	Fan Guard
2	18-6304-01	Fan Blade
3	18-5301-01	Fan Motor
	16-0850-03	Male fitting (3/8)
	16-0850-01	Male fitting (1/2)
For Precharg	ged Line set:	
4	16-1057-01	Female coupling (3/8")
5	16-1057-02	Female coupling (1/2")

MCM1062R SERVICE PARTS MDB560 ICE STORAGE BIN SERVICE PARTS




MDB550 ICE STORAGE BIN



MDB550

ITEM **PART ITEM PART** NUMBER NUMBER **DESCRIPTION** NUMBER NUMBER **DESCRIPTION** Canopy 1 A33921-001 14 02-2809-01 Drain Top 2 a32580-001 Baffle 15 13-0617-11 O-Ring 3 19-0503-04 Gasket 16 Leg, not used. no number 02-3111-01 4 Door Frame Front caster, swivel A33922-020 17 5 Back caster A33938-020 Door 02-3110-01 13-0595-00 6 Door Gasket, 6' req. 18 03-1404-06 Screw 7 A32396-002 Hinge Right 19 03-1360-02 Screw 8 A32396-001 Hinge Left 20 not used no number 9 Hinge Bushing 21 02-2380-02 03-1418-41 Screw 10 02-2380-02 Hinge Spacer 22 A32546-001 Door hinge left 11 **Shoulder Screw** Door hinge right 02-2806-01 23 A32546-002 12 03-1539-09 E-Clip 24 03-1423-07 Speed nut for baffle 13 03-0727-06 Thumb Screw


WIRING DIAGRAM 208-230/60/3



SCHEMATIC DIAGRAM 208-230/60/3

CAUTION:

MORE THAN ONE DISCONNECT MEANS MAY BE REQUIRED TO DISCONNECT ALL POWER TO THIS UNIT.



USE COPPER CONDUCTORS ONLY

NOTE:

MATERIAL TO MEET SPECIFICATIONS LISTED ON REF. DRAWING 19-0550-01

April, 1993 Page 10